

REGULATING SOLENOID VALVE [SKYACTIV-D 2.2]


id0113z7265100

Purpose, Function

- Vacuum generated by the vacuum pump operation is introduced to the regulating valve actuator.
- The regulating valve opens according to the control signal from the PCM.

Construction

- The regulating solenoid valve is installed to the vacuum pipe bracket on the side of the turbocharger.




ac5wzn00002192

- The regulating solenoid valve consists of a coil, spring, and plunger.

Operation

- According to the control signal from the PCM, the coil is energized and the plunger is operated to open/close the regulating solenoid valve.



ac5wzn00002193

- Vacuum generated by the vacuum pump operation is introduced to the regulating valve actuator by the opening of the regulating solenoid valve.

Fail-safe

- Function not equipped.