



DTC P0047:00 [SKYACTIV-D 2.2]


id0102s4345700

DTC P0047:00	Regulating solenoid valve control circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> If the PCM detects that the regulating solenoid valve voltage at the PCM terminal 1CP is 0.19 V or less for 1 s with the following condition met, the PCM determines that the regulating solenoid valve circuit voltage is low. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits engine-stop by operating the i-stop function. PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Regulating solenoid valve connector or terminals malfunction Short to ground or open circuit in regulating solenoid valve power supply circuit <ul style="list-style-type: none"> Short to ground in wiring harness between ENGINE2 15 A fuse and regulating solenoid valve terminal A ENGINE2 15 A fuse malfunction Open circuit in wiring harness between main relay terminal C and regulating solenoid valve terminal A Short to ground in wiring harness between regulating solenoid valve terminal B and PCM terminal 1CP PCM connector or terminals malfunction Open circuit in wiring harness between regulating solenoid valve terminal B and PCM terminal 1CP Regulating solenoid valve malfunction PCM malfunction



PCM WIRING HARNESS-SIDE CONNECTOR

1EE 1EA 1DW 1DS 1DO 1DK 1DG 1EF 1EB 1DX 1DT 1DP 1DL 1DH	1DA 1CW 1CS 1CO 1CK 1CG 1CC 1BY 1DB 1CX 1CT 1CP 1CL 1CH 1CD 1BZ	1BR 1BM 1BH 1BC 1AX 1AS 1AN 1AI 1BS 1BN 1BI 1BD 1AY 1AT 1AO 1AJ	1AD 1Y 1T 1O 1J 1E 1A 1AE 1Z 1U 1P 1K 1F 1B
1EI 1EG 1EC 1DY 1DU 1DQ 1DM 1DI 1EJ 1EH 1ED 1DZ 1DV 1DR 1DN 1DJ	1DE 1DC 1CY 1CU 1CQ 1CM 1CI 1CE 1CA 1BW 1DF 1DD 1CZ 1CV 1CR 1CN 1CJ 1CF 1CB 1BX	1BT 1BO 1BJ 1BE 1AZ 1AU 1AP 1AK 1BU 1BP 1BK 1BF 1BA 1AV 1AQ 1AL	1AF 1AA 1V 1Q 1L 1G 1C 1AG 1AB 1W 1R 1M 1H 1D
		1BV 1BQ 1BL 1BG 1BB 1AW 1AR 1AM	1AH 1AC 1X 1S 1N 1I



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes No	Go to the next step. Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	INSPECT REGULATING SOLENOID VALVE CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the regulating solenoid valve connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	INSPECT REGULATING SOLENOID VALVE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the regulating solenoid valve connector is disconnected. Switch the ignition ON (engine off). Measure the voltage at the regulating solenoid valve terminal A (wiring harness-side). Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE2 15 A fuse. <ul style="list-style-type: none"> If the fuse is blown: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. Replace the fuse. If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the fuse. If the fuse is normal: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible open circuit. Go to Step 9.
5	INSPECT REGULATING SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the regulating solenoid valve connector is disconnected. Switch the ignition off. Inspect for continuity between regulating solenoid valve terminal B (wiring harness-side) and body ground. Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 9.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
7	INSPECT REGULATING SOLENOID VALVE CONTROL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the regulating solenoid valve and PCM connectors are disconnected. Inspect for continuity between regulating solenoid valve terminal B (wiring harness-side) and PCM terminal 1CP (wiring harness-side). Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT REGULATING SOLENOID VALVE <ul style="list-style-type: none"> Inspect the regulating solenoid valve. (See REGULATING SOLENOID VALVE INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the regulating solenoid valve, then go to the next step. (See REGULATING SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.