


DTC U0298:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4910500

DTC U0298:00	CAN/LIN communication system: DC-DC converter information communication error with front body control module (FBCM)
DETECTION CONDITION	<ul style="list-style-type: none">• PCM detects a DC-DC converter information communication error from front body control module (FBCM). Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (other).• The check engine light does not illuminate.• FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Inhibits engine-stop by operating the i-stop function.
VEHICLE STATUS WHEN DTCs ARE OUTPUT	<ul style="list-style-type: none">• Flashes i-stop warning light (amber).
POSSIBLE CAUSE	<ul style="list-style-type: none">• Communication line between DC-DC converter and front body control module (FBCM) malfunction• DC-DC converter connector or terminals malfunction• Short to ground or open circuit in DC-DC converter power supply circuit<ul style="list-style-type: none">— Short to ground in wiring harness between DCDC 50 A fuse and DC-DC converter terminal L— DCDC 50 A fuse malfunction— Open circuit in wiring harness between battery positive terminal and DC-DC converter terminal L• Short to ground or open circuit in DC-DC converter power supply circuit<ul style="list-style-type: none">— Short to ground in wiring harness between C/U IG1 15 A fuse and DC-DC converter terminal H— C/U IG1 15 A fuse malfunction— Open circuit in wiring harness between IG1 relay terminal C and DC-DC converter terminal H• Front body control module (FBCM) connector or terminals malfunction• Short to ground in wiring harness between the following terminals:<ul style="list-style-type: none">— DC-DC converter terminal C—Front body control module (FBCM) terminal 2H— Front body control module (FBCM) terminal 2P—PCM terminal 2AK— Front body control module (FBCM) terminal 2N—PCM terminal 2AL• Open circuit in wiring harness between DC-DC converter terminal C and front body control module (FBCM) terminal 2H• DC-DC converter malfunction• Front body control module (FBCM) malfunction



Repeatability Verification Procedure

1. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
2. Start the engine.

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none"> • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
3	INSPECT DC-DC CONVERTER CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the DC-DC converter connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
4	INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter connector is disconnected. • Measure the voltage at the DC-DC converter terminal L (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the DCDC 50 A fuse. <ul style="list-style-type: none"> • If the fuse is burnt out: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between DCDC 50 A fuse and DC-DC converter terminal L. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. • Replace the fuse. • If the fuse is damaged: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and DC-DC converter terminal L. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 12.

STEP	INSPECTION	ACTION	
5	INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter connector is disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the DC-DC converter terminal H (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the C/U IG1 15 A fuse. <ul style="list-style-type: none"> • If the fuse is burnt out: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between C/U IG1 15 A fuse and DC-DC converter terminal H. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. • Replace the fuse. <ul style="list-style-type: none"> • If the fuse is damaged: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between IG1 relay terminal C and DC-DC converter terminal H. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 12.
6	INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the front body control module (FBCM) connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
7	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected. • Inspect for continuity between DC-DC converter terminal C (wiring harness-side) and body ground. • Is there continuity? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between DC-DC converter terminal C and front body control module (FBCM) terminal 2H. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. Go to Step 12.
		No	Go to the next step.

STEP	INSPECTION		ACTION
8	INSPECT FRONT BODY CONTROL MODULE (FBCM) CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Front body control module (FBCM) terminal 2P — Front body control module (FBCM) terminal 2N • Is there continuity? 	Yes	<p>If the short to ground circuit could be detected in the wiring harness:</p> <ul style="list-style-type: none"> • Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> — Front body control module (FBCM) terminal 2P—PCM terminal 2AK — Front body control module (FBCM) terminal 2N—PCM terminal 2AL <p>If there is a common connector:</p> <ul style="list-style-type: none"> — Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. — Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> — Repair or replace the wiring harness which has a short to ground. <p>If the short to ground circuit could not be detected in the wiring harness:</p> <ul style="list-style-type: none"> • Replace the front body control module (FBCM) or DC-DC converter. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.) (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) <p>Go to Step 12.</p>
		No	Go to the next step.
9	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected. • Inspect for continuity between DC-DC converter terminal C (wiring harness-side) and front body control module (FBCM) terminal 2H (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	<p>Refer to the wiring diagram and verify whether or not there is a common connector between DC-DC converter terminal C and front body control module (FBCM) terminal 2H.</p> <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. <p>Go to Step 12.</p>
10	INSPECT DC-DC CONVERTER <ul style="list-style-type: none"> • Inspect the DC-DC converter. (See DC-DC CONVERTER INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is there any malfunction? 	Yes	Replace the DC-DC converter, then go to Step 12. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
11	INSPECT FRONT BODY CONTROL MODULE (FBCM) <ul style="list-style-type: none"> • Inspect the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) INSPECTION.) • Is there any malfunction? 	Yes	Replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
12	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Implement the repeatability verification procedure. (See Repeatability Verification Procedure.) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1.
		No	Go to the next step.
13	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.