


DTC P2147:00 [SKYACTIV-D 2.2]

id0102s4152700


DTC P2147:00	Fuel injector No.1 and No.4 circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> • When the following condition is met, the PCM detects the control current at fuel injectors No.1 and No.4 as exceeding 35 A 4 times or control voltage at fuel injectors No.1 and No.4 as 40 V or less 4 times: <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> — Battery voltage: more than 8 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is an intermittent monitor (fuel system). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • PCM restricts engine torque. • Inhibits the EGR control. • Inhibits the diesel particulate filter regeneration control. • Inhibits engine-stop by operating the i-stop function. • PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Fuel injector No.1 connector or terminals malfunction • Fuel injector No.4 connector or terminals malfunction • Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> — Fuel injector No.1 terminal A—PCM terminal 1EA — Fuel injector No.1 terminal B—PCM terminal 1EE — Fuel injector No.4 terminal A—PCM terminal 1DW — Fuel injector No.4 terminal B—PCM terminal 1EF • PCM connector or terminals malfunction • Fuel injector No.1 malfunction • Fuel injector No.4 malfunction • PCM malfunction

**DTC
P2147:00**

Fuel injector No.1 and No.4 circuit low input



PCM WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT FUEL INJECTOR NO.1 CONNECTOR CONDITION • Switch the ignition off. • Disconnect the fuel injector No.1 connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
4	INSPECT FUEL INJECTOR NO.4 CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the fuel injector No.4 connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	INSPECT FUEL INJECTOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the fuel injector No.1 and fuel injector No.4 connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Fuel injector No.1 terminal A — Fuel injector No.1 terminal B — Fuel injector No.4 terminal A — Fuel injector No.4 terminal B • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 9.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
7	INSPECT FUEL INJECTOR NO.1 <ul style="list-style-type: none"> • Inspect the fuel injector No.1. (See FUEL INJECTOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the fuel injector No.1, then go to Step 9. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
8	INSPECT FUEL INJECTOR NO.4 <ul style="list-style-type: none"> • Inspect the fuel injector No.4. (See FUEL INJECTOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the fuel injector No.4, then go to the next step. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.