
BLIND SPOT MONITORING (BSM) INDICATOR LIGHT REMOVAL/INSTALLATION

id092200014300

Note

- The BSM indicator lights are integrated into the outer mirror glass.
- For the BSM indicator light removal/installation, refer to the outer mirror glass removal/installation. (See OUTER MIRROR GLASS REMOVAL.) (See OUTER MIRROR GLASS INSTALLATION.)