


Caution

- Vehicle specifications differ depending on the vehicle identification number (VIN).
 - Type A VIN:
 - JM0 KE***** 100001—
 - JM6 KE***** 100001—
 - JM7 KE***** 100001—
 - JM8 KE***** 100001—
 - JMZ KE***** 100001—
 - KE10** 100001—
 - Type B VIN:
 - JM0 KE***** 200001—
 - JM6 KE***** 200001—
 - JM8 KE***** 200001—
 - JMZ KE***** 200001—
 - KE10** 200001—

DTC P0072:00	Ambient temperature sensor circuit low input
DETECTION CONDITION	<p>Type A VIN</p> <ul style="list-style-type: none"> The PCM monitors the input signal from the ambient temperature sensor. If the voltage from the ambient temperature sensor is below 0.2 V for 5 s, the PCM determines that the ambient temperature sensor circuit has a malfunction. <p>Type B VIN</p> <ul style="list-style-type: none"> The PCM monitors the input signal from the ambient temperature sensor. If the voltage from the ambient temperature sensor is below 0.18 V, the PCM determines that the ambient temperature sensor circuit has a malfunction. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none"> Ambient temperature sensor connector or terminals malfunction Ambient temperature sensor malfunction Short to ground in wiring harness between ambient temperature sensor terminal A and PCM terminal 2I PCM connector or terminals malfunction Ambient temperature sensor signal circuit and ground circuit are shorted to each other PCM malfunction



Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none"> If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	INSPECT AMBIENT TEMPERATURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the ambient temperature sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
3	INSPECT AMBIENT TEMPERATURE SENSOR <ul style="list-style-type: none"> Inspect the ambient temperature sensor. (See AMBIENT TEMPERATURE SENSOR INSPECTION [MANUAL AIR CONDITIONER].) (See AMBIENT TEMPERATURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER].) Is there any malfunction? 	Yes	Replace the ambient temperature sensor, then go to Step 7. (See AMBIENT TEMPERATURE SENSOR REMOVAL/ INSTALLATION [MANUAL AIR CONDITIONER].) (See AMBIENT TEMPERATURE SENSOR REMOVAL/ INSTALLATION [FULL-AUTO AIR CONDITIONER].)
		No	Go to the next step.
4	INSPECT AMBIENT TEMPERATURE SENSOR SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the ambient temperature sensor connector is disconnected. Inspect for continuity between ambient temperature sensor terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to Step 7.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
6	INSPECT AMBIENT TEMPERATURE SENSOR SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the ambient temperature sensor and PCM connectors are disconnected. • Inspect for continuity between ambient temperature sensor terminals A and B (wiring harness-side). • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to the next step.
		No	Go to the next step.
7	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Start the engine and warm it up completely. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.