
SYMPTOM TROUBLESHOOTING [ADAPTIVE FRONT LIGHTING SYSTEM (AFS)]

id0903k9378800

No.	Troubleshooting item	Description
1	AFS OFF INDICATOR LIGHT ILLUMINATES CONTINUOUSLY [ADAPTIVE FRONT LIGHTING SYSTEM (AFS)]	<ul style="list-style-type: none">Inspect the AFS OFF indicator light with the ignition switched ON and the AFS OFF indicator light illumination off (AFS operating).
2	ADAPTIVE FRONT LIGHTING SYSTEM (AFS) OPERATES EVEN THOUGH THE AFS OFF SWITCH IS TURNED ON [ADAPTIVE FRONT LIGHTING SYSTEM (AFS)]	<ul style="list-style-type: none">AFS operates with the AFS OFF switch on (system stopped condition).
3	THE HEADLIGHT AUTO LEVELING SYSTEM DOES NOT OPERATE IN RESPONSE TO VEHICLE POSTURE [ADAPTIVE FRONT LIGHTING SYSTEM (AFS)]	<ul style="list-style-type: none">The headlight auto leveling system does operate in response to the number of occupants, cargo load in trunk, and the fuel level.One side of the headlight leveling actuator does not operate.