


DSC HU/CM INSPECTION

id041500801100

1. Disconnect the DSC HU/CM connector. (See DSC HU/CM REMOVAL/INSTALLATION.)
2. Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].), (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].), (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
3. Attach the tester lead to the DSC HU/CM wiring harness-side connector and inspect voltage, continuity, or resistance according to the standard (reference) on the table.

Standard (Reference)



ac5wzw00000003

Terminal	Signal name	Connected to	Measured item	Measured terminal (measurement condition)	Standard	Inspection item(s)
A	Power supply (solenoid operation)	Battery	Voltage	Under any condition	B+	• Wiring harness (A—battery)
B	Power supply (motor operation)	Battery	Voltage	Under any condition	B+	• Wiring harness (B—battery)
C	RF wheel-speed (-)	RF ABS wheel-speed sensor	Continuity	C—RF ABS wheel-speed sensor terminal B	Continuity detected	• Wiring harness (C—RF ABS wheel-speed sensor terminal B)
D	—	—	—	—	—	—
E	—	—	—	—	—	—
F	RF wheel-speed (+)	RF ABS wheel-speed sensor	Continuity	F—RF ABS wheel-speed sensor terminal A	Continuity detected	• Wiring harness (F—RF ABS wheel-speed sensor terminal A)
G	—	—	—	—	—	—
H	—	—	—	—	—	—
I	—	—	—	—	—	—
J	—	—	—	—	—	—
K	—	—	—	—	—	—
L	LR wheel-speed (+)	LR ABS wheel-speed sensor	Continuity	L—LR ABS wheel-speed sensor terminal A	Continuity detected	• Wiring harness (L—LR ABS wheel-speed sensor terminal A)
M	—	—	—	—	—	—
N	—	—	—	—	—	—
O	LR wheel-speed (-)	LR wheel-speed sensor	Continuity	O—LR ABS wheel-speed sensor terminal B	Continuity detected	• Wiring harness (O—LR ABS wheel-speed sensor terminal B)
P	CAN2_L	SAS control module	This terminal is used for communication and cannot be used for malfunction determination during terminal voltage inspection. Perform a DTC inspection.			
Q	Power supply (system)	Ignition switch	Voltage	Ignition switched ON (engine off). Switch the ignition to off.	B+ 1 V or less	• Wiring harness (Q—ignition switch)
R	—	—	—	—	—	—

Terminal	Signal name	Connected to	Measured item	Measured terminal (measurement condition)	Standard	Inspection item(s)
S	CAN2_H	SAS control module	This terminal is used for communication and cannot be used for malfunction determination during terminal voltage inspection. Perform a DTC inspection.			
T	—	—	—	—	—	—
U	—	—	—	—	—	—
V	—	—	—	—	—	—
W	—	—	—	—	—	—
X	RR wheel-speed (-)	RR ABS wheel-speed sensor	Continuity	X—RR ABS wheel-speed sensor terminal B	Continuity detected	• Wiring harness (X—RR ABS wheel-speed sensor terminal B)
Y	—	—	—	—	—	—
Z	—	—	—	—	—	—
AA	RR wheel-speed (+)	RR ABS wheel-speed sensor	Continuity	AA—RR ABS wheel-speed sensor terminal A	Continuity detected	• Wiring harness (AA—RR ABS wheel-speed sensor terminal A)
AB	—	—	—	—	—	—
AC	CAN_L	CAN module	This terminal is used for communication and cannot be used for malfunction determination during terminal voltage inspection. Perform a DTC inspection.			
AD	—	—	—	—	—	—
AE	—	—	—	—	—	—
AF	CAN_H	CAN module	This terminal is used for communication and cannot be used for malfunction determination during terminal voltage inspection. Perform a DTC inspection.			
AG	LF wheel-speed sensor (+)	LF ABS wheel-speed sensor	Continuity	AG—LF ABS wheel-speed sensor terminal A	Continuity detected	• Wiring harness (AG—LF ABS wheel-speed sensor terminal A)
AH	—	—	—	—	—	—
AI	Brake light (vehicles with smart city brake support (SCBS))	Brake light relay	Voltage	Brake pedal depressed	B+	• Wiring harness (AI—Brake light relay terminal D)
				Brake pedal released	1 V or less	
AJ	LF wheel-speed sensor (-)	LF wheel-speed sensor	Continuity	AJ—LF ABS wheel-speed sensor terminal B	Continuity detected	• Wiring harness (AJ—LF ABS wheel-speed sensor terminal B)
AK	—	—	—	—	—	—
AL	Ground	Ground point	Continuity	AL—ground point	Continuity detected	• Wiring harness (AL—ground point)