






<b>DTC P009B:00</b>	<b>Fuel pressure relief valve signal circuit problem</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>The operation amount of the fuel pressure relief valve is the specified value or more when the following conditions are met:  <b>MONITORING CONDITIONS</b> <ul style="list-style-type: none"> <li>Battery voltage: <b>10—16 V</b></li> </ul> </li> <li><b>Diagnostic support note</b></li> <li>This is an intermittent monitor (fuel system).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>PCM restricts engine torque.</li> <li>PCM restricts fuel pressure. (high pressure side).</li> <li>Inhibits engine-stop by operating the i-stop function.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>Fuel pressure relief valve connector or terminals malfunction</li> <li>Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>Fuel pressure relief valve terminal A—PCM terminal 1DK</li> <li>Fuel pressure relief valve terminal B—PCM terminal 1DG</li> </ul> </li> <li>PCM connector or terminals malfunction</li> <li>Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>Fuel pressure relief valve terminal A—PCM terminal 1DK</li> <li>Fuel pressure relief valve terminal B—PCM terminal 1DG</li> </ul> </li> <li>Fuel pressure relief valve circuits are shorted to each other</li> <li>Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>Fuel pressure relief valve terminal A—PCM terminal 1DK</li> <li>Fuel pressure relief valve terminal B—PCM terminal 1DG</li> </ul> </li> <li>Fuel pressure relief valve malfunction</li> <li>PCM malfunction</li> </ul>
<div style="text-align: center;"> <p>⑨</p> <p>FUEL PRESSURE RELIEF VALVE</p>  <p>FUEL PRESSURE RELIEF VALVE WIRING HARNESS-SIDE CONNECTOR</p>   <p>PCM WIRING HARNESS-SIDE CONNECTOR</p>   </div>	

## Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>INSPECT FUEL PRESSURE RELIEF VALVE CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the fuel pressure relief valve connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
4	<b>INSPECT FUEL PRESSURE RELIEF VALVE SIGNAL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>Verify that the fuel pressure relief valve connector is disconnected.</li> <li>Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>Fuel pressure relief valve terminal A</li> <li>Fuel pressure relief valve terminal B</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 10.
		No	Go to the next step.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	<b>INSPECT FUEL PRESSURE RELIEF VALVE SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>Verify that the fuel pressure relief valve and PCM connectors are disconnected.</li> <li>Switch the ignition ON (engine off).</li> <li>Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>Fuel pressure relief valve terminal A</li> <li>Fuel pressure relief valve terminal B</li> </ul> </li> <li>Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 10.
7	<b>INSPECT FUEL PRESSURE RELIEF VALVE CIRCUIT FOR SHORT TO EACH OTHER</b> <ul style="list-style-type: none"> <li>Verify that the fuel pressure relief valve and PCM connectors are disconnected.</li> <li>Switch the ignition off.</li> <li>Inspect for continuity between fuel pressure relief valve terminals A and B (wiring harness-side).</li> <li>Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 10.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
8	<b>INSPECT FUEL PRESSURE RELIEF VALVE SIGNAL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the fuel pressure relief valve and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Fuel pressure relief valve terminal A—PCM terminal 1DK</li> <li>— Fuel pressure relief valve terminal B—PCM terminal 1DG</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 10.
9	<b>INSPECT FUEL PRESSURE RELIEF VALVE</b> <ul style="list-style-type: none"> <li>• Inspect the fuel pressure relief valve. (See FUEL PRESSURE RELIEF VALVE INSPECTION [SKYACTIV-D 2.2].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the common rail, then go to the next step. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
10	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Start the engine.</li> <li>• Repeat deceleration <b>10 times</b> using engine braking after accelerating the vehicle speed to <b>60 km/h {37 mph}</b>.</li> <li>• Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
11	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.