

---

## CLEARING DTC

id080200080600

### **CMDTC Self Test**

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
  - (1) Select "Module programming".
  - (2) Select "All CMDTCs".
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition to off.
6. Switch the ignition ON (engine off or on) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION.)
8. Verify that no DTCs are displayed.

### **ODDTC Self Test**

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
  - (1) Select "Module programming".
  - (2) Select "Programmable Module Installation".
  - (3) Select "RCM".
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition to off.
6. Switch the ignition ON (engine off or on) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION.)
8. Verify that no DTCs are displayed.