







DTC B13C3:29 [ADVANCED KEYLESS ENTRY SYSTEM]

id0902p8027200

| | |
|---|---|
| System malfunction location | Communication error with LF control unit |
| Detection condition | <ul style="list-style-type: none"> The start stop unit detects communication error with LF control unit 10 times in a series. |
| Fail-safe | <ul style="list-style-type: none"> Inhibits the door lock/unlock control using the advanced keyless entry system. |
| Possible cause | <ul style="list-style-type: none"> LF control unit connector or terminal malfunction Start stop unit connector or terminal malfunction Short to ground in wiring harness between start stop unit terminal 2F and LF control unit terminal M Open circuit in wiring harness between start stop unit terminal 2F and LF control unit terminal M LF control unit malfunction Start stop unit malfunction |
| <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>START STOP UNIT</p>  <p>START STOP UNIT WIRING HARNESS-SIDE CONNECTOR</p>   </div> <div style="text-align: center;"> <p>LF CONTROL UNIT</p>  <p>LF CONTROL UNIT WIRING HARNESS-SIDE CONNECTOR</p>   </div> </div> <p>The diagram shows a communication line between terminal 2F of the Start Stop Unit and terminal M of the LF Control Unit. Below each unit is a detailed view of its wiring harness-side connector with terminal labels and a corresponding pinout diagram.</p> | |

Diagnostic Procedure

| Step | Inspection | Action | |
|------|---|--------|---|
| 1 | INSPECT LF CONTROL UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Disconnect the LF control unit connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 6. |
| 2 | INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the start stop unit connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 6. |

| Step | Inspection | Action | |
|------|--|--------|--|
| 3 | INSPECT LF CONTROL UNIT CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the start stop unit and LF control unit connectors are disconnected. Inspect for continuity between LF control unit terminal M (vehicle wiring harness side) and body ground. Is there continuity? | Yes | Repair or replace the wiring harness which is shorted to ground, then go to Step 6. |
| | | No | Go to the next step. |
| 4 | INSPECT LF CONTROL UNIT CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the start stop unit and LF control unit connectors are disconnected. Inspect the wiring harness for continuity between start stop unit terminal 2F (vehicle wiring harness side) and LF control unit terminal M (vehicle wiring harness side). Is there continuity? | Yes | Go to the next step. |
| | | No | Repair or replace the wiring harness which has an open circuit, then go to Step 6. |
| 5 | INSPECT LF CONTROL UNIT <ul style="list-style-type: none"> Inspect the LF control unit. (See LF CONTROL UNIT INSPECTION.) Is the LF control unit normal? | Yes | Go to the next step. |
| | | No | Replace the LF control unit, then go to the next step. (See LF CONTROL UNIT REMOVAL/INSTALLATION.) |
| 6 | VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> Reconnect all the disconnected connectors. Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Clear DTCs for the advanced keyless entry system using the M-MDS. (See CLEARING DTC [ADVANCED KEYLESS ENTRY SYSTEM].) Perform the advanced keyless entry system DTC inspection using the M-MDS. (See DTC INSPECTION [ADVANCED KEYLESS ENTRY SYSTEM].) Is DTC B13C3:29 displayed? | Yes | Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.) |
| | | No | Go to the next step. |
| 7 | VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> Are any other DTCs displayed? | Yes | Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ADVANCED KEYLESS ENTRY SYSTEM].) |
| | | No | DTC troubleshooting completed. |