

DTC TABLE [REAR BODY CONTROL MODULE (RBCM)]

id0902p4012800

×: Applicable
—: Not applicable

DTC No.	Warning/ indicator light	Description	Fail- safe function	Drive cycle	Self test type*1	Memory function	Page
B1079:13	—	Bonnet latch switch circuit malfunction	—	—	D	—	(See DTC B1079:13 [REAR BODY CONTROL MODULE (RBCM)].)
B108F:16*2	—	Door lock switch (LH) circuit malfunction	—	—	D	—	(See DTC B108F:16 [REAR BODY CONTROL MODULE (RBCM)].)
B109E:87	—	Communication error with start stop unit	—	—	C, D	×	(See DTC B109E:87 [REAR BODY CONTROL MODULE (RBCM)].)
B109F:49*3	—	Intruder sensor internal malfunction	—	—	C, D	×	(See DTC B109F:49 [REAR BODY CONTROL MODULE (RBCM)].)
B109F:86*3	—	Intruder sensor signal error	—	—	C, D	×	(See DTC B109F:86 [REAR BODY CONTROL MODULE (RBCM)].)
B109F:87*3	—	Communication error with intruder sensor	—	—	C, D	×	(See DTC B109F:87 [REAR BODY CONTROL MODULE (RBCM)].)
B10A5:49*3	—	Theft-deterrent siren internal malfunction	—	—	C, D	×	(See DTC B10A5:49 [REAR BODY CONTROL MODULE (RBCM)].)
B10A5:86*3	—	Theft-deterrent siren signal error	—	—	C, D	×	(See DTC B10A5:86 [REAR BODY CONTROL MODULE (RBCM)].)
B10A5:87*3	—	Communication error with theft-deterrent siren	—	—	C, D	×	(See DTC B10A5:87 [REAR BODY CONTROL MODULE (RBCM)].)
B113E:11	—	Liftgate opener switch circuit malfunction	—	—	D	—	(See DTC B113E:11 [REAR BODY CONTROL MODULE (RBCM)].)
B1172:11	—	Front door lock-link switch (driver's side) unlock circuit malfunction	—	—	D	—	(See DTC B1172:11 [REAR BODY CONTROL MODULE (RBCM)].)
B1172:13	—	Front door lock-link switch (driver's side) unlock circuit malfunction	—	—	D	—	(See DTC B1172:13 [REAR BODY CONTROL MODULE (RBCM)].)
B1174:11*3	—	Front door lock-link switch (passenger's side)/rear door lock-link switch (LH)/(RH) unlock circuit malfunction	—	—	D	—	(See DTC B1174:11 [REAR BODY CONTROL MODULE (RBCM)].)
B1174:13*3	—	Front door lock-link switch (passenger's side)/rear door lock-link switch (LH)/(RH) unlock circuit malfunction	—	—	D	—	(See DTC B1174:13 [REAR BODY CONTROL MODULE (RBCM)].)

DTC No.	Warning/ indicator light	Description	Fail- safe function	Drive cycle	Self test type *1	Memory function	Page
B1175:11	—	Front door latch switch (driver's side) circuit malfunction	—	—	D	—	(See DTC B1175:11 [REAR BODY CONTROL MODULE (RBCM)].)
B1176:11	—	Front door latch switch (passenger's side) circuit malfunction	—	—	D	—	(See DTC B1176:11 [REAR BODY CONTROL MODULE (RBCM)].)
B1178:11	—	Liftgate latch switch circuit malfunction	—	—	D	—	(See DTC B1178:11 [REAR BODY CONTROL MODULE (RBCM)].)
B11DA:16	—	Front door key cylinder switch (driver's side) circuit malfunction	—	—	D	—	(See DTC B11DA:16 [REAR BODY CONTROL MODULE (RBCM)].)
B11E9:11	—	Rear door latch switch (LH) circuit malfunction	—	—	D	—	(See DTC B11E9:11 [REAR BODY CONTROL MODULE (RBCM)].)
B11EA:11	—	Rear door latch switch (RH) circuit malfunction	—	—	D	—	(See DTC B11EA:11 [REAR BODY CONTROL MODULE (RBCM)].)
B126A:11	—	Front door lock-link switch (driver's side) lock circuit malfunction	—	—	D	—	(See DTC B126A:11 [REAR BODY CONTROL MODULE (RBCM)].)
B126A:13	—	Front door lock-link switch (driver's side) lock circuit malfunction	—	—	D	—	(See DTC B126A:13 [REAR BODY CONTROL MODULE (RBCM)].)
B1A79:13 *4	—	Rear fog light circuit malfunction	—	—	C, D	×	(See DTC B1A79:13 [REAR BODY CONTROL MODULE (RBCM)].)
C0023:14 *5	—	Rear body control module (RBCM) internal malfunction (brake light drive circuit)	—	—	C, D	×	(See DTC C0023:14 [REAR BODY CONTROL MODULE (RBCM)].)
U0010:88	—	Unit communication error (MS-CAN)	—	—	C, D	×	(See DTC U0010:88/ U0155:00 [REAR BODY CONTROL MODULE (RBCM)].)
U0155:00	—	Communication error with instrument cluster	—	—	C, D	×	
U0447:86 *4	—	Communication error between front body control module (FBCM) and instrument cluster	—	—	C, D	×	(See DTC U0447:86 [REAR BODY CONTROL MODULE (RBCM)].)
U2100:00	—	Rear body control module (RBCM) configuration error	—	—	C, D	×	(See DTC U2100:00 [REAR BODY CONTROL MODULE (RBCM)].)
U3000:49	—	Rear body control module (RBCM) internal malfunction	—	—	C, D	×	(See DTC U3000:49 [REAR BODY CONTROL MODULE (RBCM)].)
U3003:16	—	Rear body control module (RBCM) power supply voltage (+B power supply) low input	—	—	C, D	×	(See DTC U3003:16 [REAR BODY CONTROL MODULE (RBCM)].)

*1 : C: CMDTC self test, D: ODDTC self test

*2 : With 2-step unlocking

*3 : With theft-deterrent system

*4 : Vehicles with rear fog light

*5 : Vehicles with smart city brake support