


# DTC P1708:24 [START STOP UNIT]


id0902p6023500

|                             |  |
|-----------------------------|--|
| System malfunction location | Starter interlock switch circuit malfunction   |
| Detection condition         | • The start stop unit detects an open circuit in the starter interlock switch circuit for <b>1 s or more</b> for a continuous <b>5 times</b> with the ignition switched ON (engine off or on).   |
| Fail-safe                   | • Change to the back-up mode.  |
| Possible cause              | • Starter interlock switch connector or terminal malfunction<br>• Open circuit in wiring harness between starter interlock switch terminal B and body ground<br>• Starter interlock switch malfunction<br>• Start stop unit connector or terminal malfunction<br>• Open circuit in wiring harness between start stop unit terminal 1F and starter interlock switch terminal A<br>• Start stop unit malfunction |


START STOP UNIT




STARTER INTERLOCK SWITCH





START STOP UNIT WIRING HARNESS-SIDE CONNECTOR





STARTER INTERLOCK SWITCH WIRING HARNESS-SIDE CONNECTOR





## Diagnostic Procedure

| Step | Inspection   | Action   |
|------|--|--|
| 1    | <b>STARTER INTERLOCK SWITCH CONNECTOR INSPECTION</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>Disconnect the starter interlock switch connector.</li> <li>Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>Is the connector normal?</li> </ul> | Yes<br>Go to the next step.  |
|      |  | No<br>Repair or replace the connector, then go to Step 6.                                |
| 2    | <b>INSPECT STARTER INTERLOCK SWITCH GROUND CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the start stop unit and starter interlock switch connectors are disconnected.</li> <li>Inspect for continuity between starter interlock switch terminal B (vehicle wiring harness side) and body ground.</li> <li>Is there continuity?</li> </ul>   | Yes<br>Go to the next step.  |
|      |  | No<br>Repair or replace the wiring harness which has an open circuit, then go to Step 6. |

| Step | Inspection   |     | Action   |
|------|--|-----|--|
| 3    | <b>INSPECT STARTER INTERLOCK SWITCH</b> <ul style="list-style-type: none"> <li>Inspect the starter interlock switch.<br/>(See STARTER INTERLOCK SWITCH INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)<br/>(See STARTER INTERLOCK SWITCH INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is the starter interlock switch normal?</li> </ul>   | Yes | Go to the next step.   |
|      |  | No  | Replace the starter interlock switch, then go to Step 6.<br>(See STARTER INTERLOCK SWITCH REMOVAL/INSTALLATION [C66M-R, C66MX-R].)<br>(See STARTER INTERLOCK SWITCH REMOVAL/INSTALLATION [D66M-R, D66MX-R].) |
| 4    | <b>INSPECT START STOP UNIT CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the start stop unit connector.</li> <li>Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>Is the connector normal?</li> </ul>  | Yes | Go to the next step.   |
|      |  | No  | Repair or replace the connector, then go to Step 6.  |
| 5    | <b>INSPECT STARTER INTERLOCK SWITCH CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the start stop unit and starter interlock switch connectors are disconnected.</li> <li>Inspect the wiring harness for continuity between start stop unit terminal 1F (vehicle wiring harness side) and starter interlock switch terminal A (vehicle wiring harness side).</li> <li>Is there continuity?</li> </ul>   | Yes | Go to the next step.   |
|      |  | No  | Repair or replace the wiring harness which has an open circuit, then go to the next step.  |
| 6    | <b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>Reconnect all the disconnected connectors.</li> <li>Reconnect the disconnected negative battery cable.<br/>(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)<br/>(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)<br/>(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>Clear DTC for the start stop unit using the M-MDS.<br/>(See CLEARING DTC [START STOP UNIT].)</li> <li>Switch the ignition ON (engine off or on).</li> <li>Perform the work of depressing the clutch pedal for <b>1 s or more</b> and releasing it for <b>1 s or more for 5 or more times</b>.</li> <li>Perform the DTC inspection for the start stop unit using the M-MDS.<br/>(See DTC INSPECTION [START STOP UNIT].)</li> <li>Is DTC P1708:24 displayed?</li> </ul> | Yes | Repeat the inspection from Step 1.<br>• If the malfunction recurs, replace the start stop unit, then go to the next step.<br>(See START STOP UNIT REMOVAL/INSTALLATION.)                                     |
|      |  | No  | Go to the next step.   |
| 7    | <b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"> <li>Are any other DTCs displayed?</li> </ul>  | Yes | Repair the malfunctioning part according to the applicable DTC troubleshooting.<br>(See DTC TABLE [START STOP UNIT].)  |
|      |  | No  | DTC troubleshooting completed.   |