

DTC U0423:00/U0443:00 [DYNAMIC STABILITY CONTROL (DSC)]

id0402b2905300

DTC	U0423:00/U0443:00	Abnormal message from instrument cluster
DETECTION CONDITION	<ul style="list-style-type: none"> Correct data cannot be received from instrument cluster 	
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> U0423:00 <ul style="list-style-type: none"> Illuminates the master warning light*. Tire pressure monitoring system warning light illuminates after flashes. Inhibits the TPMS and smart city brake support (SCBS)* controls. U0443:00 <ul style="list-style-type: none"> Illuminates the master warning light*. Inhibits the smart city brake support (SCBS)* controls. <p>*: Vehicles with smart city brake support (SCBS)</p>	
POSSIBLE CAUSE	<ul style="list-style-type: none"> Instrument cluster malfunction 	
SYSTEM WIRING DIAGRAM	—	

Diagnostic procedure

STEP	INSPECTION	ACTION
1	INSPECT FOR INSTRUMENT CLUSTER MALFUNCTION <ul style="list-style-type: none"> Switch the ignition to off. Using the M-MDS, perform the DTC inspection for the instrument cluster. (See DTC INSPECTION [INSTRUMENT CLUSTER].) Are any DTCs detected? 	Yes Go to applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No Go to the next step.
2	VERIFY THAT THE SAME DTC IS NOT PRESENT <ul style="list-style-type: none"> Clear the DTCs from the memory. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) Are the same DTCs present? 	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the instrument cluster, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No Go to the next step.
3	VERIFY THAT NO OTHER DTCS ARE PRESENT <ul style="list-style-type: none"> Are any other DTCs output? 	Yes Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)
		No DTC troubleshooting completed.