

DTC P0111:00 [SKYACTIV-D 2.2]

id0102s4701300

DTC P0111:00	IAT sensor No.1 circuit range/performance problem
DETECTION CONDITION	<ul style="list-style-type: none"> The difference between the intake air temperature measured by IAT sensor No.1 and IAT sensor No.2 exceeds 50 °C {90 °F}. The difference between the intake air temperature measured by IAT sensor No.1 and boost air temperature sensor exceeds 50 °C {90 °F}. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM. PENDING CODE is available if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits the two-stage turbo control. Inhibits the EGR control. The fast idle up correction for the idle speed control is inhibited. Inhibits engine-stop by operating the i-stop function. PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> MAF sensor/IAT sensor No.1 connector or terminals malfunction IAT sensor No.1 malfunction PCM connector or terminals malfunction PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT MAF SENSOR/IAT SENSOR NO.1 CONNECTOR CONDITION • Switch the ignition off. • Disconnect the MAF sensor/IAT sensor No.1 connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.
4	INSPECT IAT SENSOR NO.1 • Inspect the IAT sensor No.1. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction?	Yes	Replace the MAF sensor/IAT sensor No.1, then go to Step 6. (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to the next step.
		No	Go to the next step.

STEP	INSPECTION	ACTION
6	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Leave the vehicle for 6 hours or more. • Start the engine and idle it for 1 min. • Perform the Pending Trouble Code Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the PENDING CODE for this DTC present? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No Go to the next step.
7	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No DTC troubleshooting completed.