

## ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FW6A-EL, FW6AX-EL]

id050227290100

### Reading DTCs Procedure

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
  - (1) Select "Self Test".
  - (2) Select "Modules".
  - (3) Select "TCM".

#### Note

- Freeze frame data/snapshot data appears at the top of the help screen when the displayed DTC is selected.

#### Freeze frame data

- The freeze frame data consists of data for vehicle and transaxle control system operation conditions when malfunctions in the transaxle control system are detected and stored in the TCM.
- Freeze frame data is stored at the instant the malfunction indicator lamp illuminates, and only a part of the DTC data is stored.

#### Snapshot data

- The data for all DTCs currently detected is stored.

#### Recorded DTC timing

- For DTCs with one drive cycle, data is recorded during the malfunction determination period.
- For DTCs with two drive cycles, data is recorded during non-determination (1st diagnosis) periods.

3. Then, select the "Retrieve CMDTCs" and perform procedures according to the directions on the M-MDS screen.
4. Verify the DTC according to the directions on the screen.
  - If any DTCs are displayed, perform troubleshooting according to the corresponding DTC inspection.
5. After completion of repairs, clear all DTCs stored in the TCM. (See Freeze frame data item table.)

### Freeze frame data item table

#### Note

- Refer to PID/DATA monitor table for confirm the transaxle control system operation status while the TCM does not store the DTC. (See ON-BOARD DIAGNOSTIC SYSTEM PID/DATA MONITOR INSPECTION [FW6A-EL, FW6AX-EL].)
- Freeze frame data items are not displayed, according to detected DTC.

| Freeze frame data item | Unit      | Description                     | —: Not applicable                   |
|------------------------|-----------|---------------------------------|-------------------------------------|
|                        |           |                                 | Corresponding PID/DATA monitor item |
| LOAD                   | %         | Calculated engine load          | —                                   |
| ECT                    | °C {°F}   | Engine coolant temperature      | ECT                                 |
| RPM                    | RPM       | Engine speed                    | RPM                                 |
| VS                     | KPH {MPH} | Vehicle speed                   | VSS                                 |
| IAT                    | °C {°F}   | Intake air temperature          | —                                   |
| TP                     | %         | Throttle valve position No.1    | —                                   |
| RUNTM                  | hh:mm:ss  | Time from engine start          | —                                   |
| VPWR                   | V         | Module supply voltage           | VPWR                                |
| APP_D                  | %         | Accelerator pedal position No.1 | —                                   |

### Snapshot data item table

#### Note

- Refer to PID/DATA monitor table for confirm the transaxle control system operation status while the TCM does not store the DTC. (See ON-BOARD DIAGNOSTIC SYSTEM PID/DATA MONITOR INSPECTION [FW6A-EL, FW6AX-EL].)
- Snapshot data items are not displayed, according to detected DTC.

—: Not applicable

| Snapshot data item | Unit  | Description  | Corresponding PID/DATA monitor item |
|--------------------|---|--|-------------------------------------|
| LOAD               | %   | Calculated engine load   | —                                   |
| ECT                | °C {°F}   | Engine coolant temperature                                       | ECT                                 |
| RPM                | RPM   | Engine speed   | RPM                                 |
| VSS                | KPH {MPH}   | Vehicle speed  | VSS                                 |
| IAT                | °C {°F}   | Intake air temperature   | —                                   |
| EG_RUN_TIME        | —   | Time from engine start   | —                                   |
| VPWR               | V   | Module supply voltage  | VPWR                                |
| APP1               | %   | Accelerator pedal position No.1                                  | —                                   |
| GEAR_SEL           | 1/2/3/4/5/6   | Gear shift position  | GEAR_SEL                            |
| TSS                | RPM   | Turbine/input shaft speed  | TSS                                 |
| TFT                | °C {°F}   | ATF temperature  | TFT                                 |
| OSS                | RPM   | Output shaft speed   | OSS                                 |
| LOCK_UP            | Off/SLIP/On   | Torque converter (TCC condition)                                 | LOCK_UP                             |
| OIL_PRES_SW2       | Off/On  | Oil pressure switch No.2 condition                               | OP_SW2                              |
| OIL_PRES_SW1       | Off/On  | Oil pressure switch No.1 condition                               | OP_SW1                              |
| SS_ON_OFF          | Off/On  | On/off solenoid condition  | SS_ON-OFF                           |
| TORQUE_DES         | Nm  | Desired engine torque  | TORQUE_DES                          |
| APP                | %   | Accelerator pedal position No.1                                  | —                                   |
| G_INHIBIT_6        | Off/On  | 6GR is inhibited due to malfunction.                             | —                                   |
| G_INHIBIT_5        | Off/On  | 5GR is inhibited due to malfunction.                             | —                                   |
| G_INHIBIT_4        | Off/On  | 4GR is inhibited due to malfunction.                             | —                                   |
| G_INHIBIT_3        | Off/On  | 3GR is inhibited due to malfunction.                             | —                                   |
| G_INHIBIT_2        | Off/On  | 2GR is inhibited due to malfunction.                             | —                                   |
| G_INHIBIT_1        | Off/On  | 1GR is inhibited due to malfunction.                             | —                                   |
| G_INHIBIT_R        | Off/On  | R position is inhibited due to malfunction.                      | —                                   |
| G_INHIBIT_N        | Off/On  | N position is inhibited due to malfunction.                      | —                                   |
| OIL_PRES_SW4       | Off/On  | Oil pressure switch No.4 condition                               | OP_SW4                              |
| OIL_PRES_SW3       | Off/On  | Oil pressure switch No.3 condition                               | OP_SW3                              |
| EOP_RLY            | Off/On  | Electric AT oil pump relay condition                             | EOP_RLY                             |
| SHIFT_CTRL         | DEFAULT/<br>MANUAL/<br>C_CONTROL/<br>HIGH_TEMP/<br>D_MANUAL/<br>FAIL_SAFE | Shift control mode   | SHIFT_CTRL                          |
| SLIP_VALUE         | RPM   | Actual slip value between TSS and OSS                            | —                                   |
| HTM_DIS            | km {mile}   | Travel distance since determination of ATF high temperature mode | HTM_DIS                             |
| MST_REC_SFT        | —   | The gear shift position before shifting gears is displayed.      | SE_TYPE                             |
| SFT_CTL_STS        | —   | The shift control execution condition is displayed.              | SC_STATE                            |
| SERIAL_DTC         | —   | DTC  | —                                   |
| TR                 | —   | Transaxle range sensor position.                                 | TR                                  |

### Clearing DTCs Procedures

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
  - (1) Select "Self Test".
  - (2) Select "Modules".
  - (3) Select "TCM".
  - (4) Select "Retrieve CMDTCs".
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition off.
6. Close all of the doors, bonnet, trunk lid, and liftgate, lock the doors, and wait for **3 min.**
7. Switch the ignition to ON (engine off or on) and wait for **5 s or more.**
8. Perform DTC inspection. (See Reading DTCs Procedure.)
9. Verify that no DTCs are displayed.