


DTC P245A:00 [SKYACTIV-D 2.2]

id0102s4125800



DTC P245A:00	EGR cooler bypass valve control: Drive circuit malfunction
DETECTION CONDITION	<ul style="list-style-type: none">• The EGR cooler bypass valve drive current exceeds the specification for a continuous 3 s when the following condition is met: MONITORING CONDITIONS<ul style="list-style-type: none">— Drive circuit temperature: 175 °C {347 °F} or more• Diagnostic support note• This is a continuous monitor (CCM).• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.• FREEZE FRAME DATA (Mode 2)/Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Inhibits the two-stage turbo control.• Inhibits the EGR control.• Inhibits engine-stop by operating the i-stop function.• PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none">• EGR cooler bypass valve/EGR cooler bypass valve position sensor connector or terminals malfunction• Short to ground in wiring harness between the following terminals:<ul style="list-style-type: none">— EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal E—PCM terminal 1BH— EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal A—PCM terminal 1BC• PCM connector or terminals malfunction• Short to power supply in wiring harness between the following terminals:<ul style="list-style-type: none">— EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal E—PCM terminal 1BH— EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal A—PCM terminal 1BC• EGR cooler bypass valve malfunction• PCM malfunction

DTC P245A:
00



EGR cooler bypass valve control: Drive circuit malfunction



EGR COOLER BYPASS VALVE/
EGR COOLER BYPASS VALVE POSITION SENSOR
WIRING HARNESS-SIDE CONNECTOR



PCM WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	VERIFY FREEZE FRAME DATA (MODE 2)/SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none">Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none">Verify related Service Information availability.Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none">If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT EGR COOLER BYPASS VALVE/EGR COOLER BYPASS VALVE POSITION SENSOR CONNECTOR CONDITION <ul style="list-style-type: none">Switch the ignition off.Disconnect the EGR cooler bypass valve/EGR cooler bypass valve position sensor connector.Inspect for poor connection (such as damaged/pulled-out pins, corrosion).Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.

STEP	INSPECTION		ACTION
4	INSPECT EGR COOLER BYPASS VALVE CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the EGR cooler bypass valve/EGR cooler bypass valve position sensor connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal E — EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal A • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 8.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
6	INSPECT EGR COOLER BYPASS VALVE CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the EGR cooler bypass valve/EGR cooler bypass valve position sensor and PCM connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> — EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal E — EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal A • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
7	INSPECT EGR COOLER BYPASS VALVE <ul style="list-style-type: none"> • Inspect the EGR cooler bypass valve. (See EGR COOLER BYPASS VALVE INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the EGR cooler bypass valve, then go to the next step. (See EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.