


DTC B11C4:23 [ADVANCED KEYLESS ENTRY SYSTEM]


id0902p8026600

| | |
|------------------------------------|--|
| System malfunction location | Request switch (liftgate) circuit malfunction |
| Detection condition | <ul style="list-style-type: none"> With the ignition switched ON (engine on), the start stop unit detects that the vehicle speed is 5 km/h {3 mph} or more for a continuous 2 min or more and the request switch (liftgate) is on 7 times or more until the vehicle speed is less than 5 km/h {3 mph}. |
| Fail-safe | — |
| Possible cause | <ul style="list-style-type: none"> Request switch (liftgate) connector or terminal malfunction LF control unit connector or terminal malfunction Short to ground in wiring harness between LF control unit terminal I and request switch (liftgate) terminal A Request switch (liftgate) malfunction LF control unit malfunction Start stop unit malfunction |


LF CONTROL UNIT




LF CONTROL UNIT
WIRING HARNESS-SIDE CONNECTOR



REQUEST SWITCH (LIFTGATE)



REQUEST SWITCH (LIFTGATE)
WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

| Step | Inspection | Action |
|------|---|---|
| 1 | INSPECT REQUEST SWITCH (LIFTGATE) CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Disconnect the request switch (liftgate) connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? | <div style="display: flex; justify-content: space-between;"> <div> <p>Yes</p> <p>No</p> </div> <div> <p>Go to the next step.</p> <p>Repair or replace the connector, then go to Step 6.</p> </div> </div> |

| Step | Inspection | Action |
|------|---|--|
| 2 | INSPECT LF CONTROL UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the LF control unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? | Yes Go to the next step. |
| | | No Repair or replace the connector, then go to Step 6. |
| 3 | INSPECT REQUEST SWITCH (LIFTGATE) CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the LF control unit and request switch (liftgate) connectors are disconnected. • Inspect for continuity between request switch (liftgate) terminal A (vehicle wiring harness side) and body ground. • Is there continuity? | Yes Repair or replace the wiring harness which is shorted to ground, then go to Step 6. |
| | | No Go to the next step. |
| 4 | INSPECT REQUEST SWITCH (LIFTGATE) <ul style="list-style-type: none"> • Inspect the request switch (liftgate). (See REQUEST SWITCH INSPECTION.) • Is the request switch (liftgate) normal? | Yes Go to the next step. |
| | | No Replace the request switch (liftgate), then go to Step 6. (See REQUEST SWITCH REMOVAL/INSTALLATION.) |
| 5 | INSPECT LF CONTROL UNIT <ul style="list-style-type: none"> • Inspect the LF control unit. (See LF CONTROL UNIT INSPECTION.) • Is the LF control unit normal? | Yes Go to the next step. |
| | | No Replace the LF control unit, then go to the next step. (See LF CONTROL UNIT REMOVAL/INSTALLATION.) |
| 6 | VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Clear DTCs for the advanced keyless entry system using the M-MDS. (See CLEARING DTC [ADVANCED KEYLESS ENTRY SYSTEM].) • Drive the vehicle at 5 km/h {3 mph} or more for 2 min or more. • Perform the advanced keyless entry system DTC inspection using the M-MDS. (See DTC INSPECTION [ADVANCED KEYLESS ENTRY SYSTEM].) • Is DTC B11C4:23 displayed? | Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.) |
| | | No Go to the next step. |
| 7 | VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? | Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ADVANCED KEYLESS ENTRY SYSTEM].) |
| | | No DTC troubleshooting completed. |