

DTC P0116:00 [SKYACTIV-G 2.0]

id0102h1146800

DTC P0116:00	ECT sensor circuit range/performance problem
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the maximum value and minimum value of engine coolant temperature when the engine is started and 5 min have been passed after leaving the vehicle 6 h or more. If difference between maximum and minimum values of engine coolant temperature is below 6 °C {43 °F} the PCM determines that there is an ECT sensor circuit range/performance problem. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (engine cooling system). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	—
POSSIBLE CAUSE	<ul style="list-style-type: none"> ECT sensor connector or terminals malfunction PCM connector or terminals malfunction ECT sensor malfunction Thermostat malfunction PCM malfunction
SYSTEM WIRING DIAGRAM	—

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA (MODE 2) <ul style="list-style-type: none"> Perform the Freeze Frame PID Data Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Is the DTC P0116:00 on FREEZE FRAME DATA (Mode 2)? 	Yes	Go to the next step.
		No	Go to the troubleshooting procedure for DTC on FREEZE FRAME DATA (Mode 2). (See DTC TABLE [SKYACTIV-G 2.0].)
2	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS HAVE BEEN RECORDED <ul style="list-style-type: none"> Have the FREEZE FRAME DATA (Mode 2)/ snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (engine cooling system related) been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS on the repair order, then go to the next step.
3	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
4	INSPECT ECT SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the ECT sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
6	INSPECT ECT SENSOR <ul style="list-style-type: none"> Inspect the ECT sensor. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the ECT sensor, then go to Step 9. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
7	COMPARE ECT PID VALUE <ul style="list-style-type: none"> Prepare a new ECT sensor. Connect the ECT sensor connector to the new one without installing to the engine. Switch the ignition ON (engine off) and record the ECT PID value. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Switch the ignition to off. Replace the malfunction ECT sensor with new one. Start the engine and wait for 5 min. Record the ECT PID value. Is the difference between each ECT PID values more than 6 °C {43 °F}? 	Yes	Go to the next step.
		No	Go to Step 9.
8	INSPECT THERMOSTAT <ul style="list-style-type: none"> Switch the ignition to off. Inspect the thermostat. (See THERMOSTAT INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the thermostat, then go to the next step. (See THERMOSTAT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Make sure to reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) Switch the ignition to off. Start the engine and warm it up completely. Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.