

**DTC P0132:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]**

id0102h4702300


**Note**

- To determine the malfunctioning part, proceed with the diagnostics from "Function Inspection Using M-MDS".

**Details On DTCs**

DESCRIPTION	A/F sensor circuit high input	
<b>DETECTION CONDITION</b>	Determination conditions	<ul style="list-style-type: none"><li>• Any one of the following conditions is met:<ul style="list-style-type: none"><li>— Voltage of A/F sensor terminal F is more than specified value</li><li>— Voltage of A/F sensor terminal D is more than specified value</li><li>— Voltage of A/F sensor terminal B is more than specified value</li></ul></li></ul>
	Preconditions	<ul style="list-style-type: none"><li>• Switch the ignition ON (engine off)</li><li>• Battery voltage: <b>11—18 V</b> *1</li><li>• The following DTC is not detected:<ul style="list-style-type: none"><li>— Internal PCM malfunction: P064D:00</li></ul></li><li>*1: Value can be verified by displaying PIDs using M-MDS</li></ul>
	Drive cycle	<ul style="list-style-type: none"><li>• 2</li></ul>
	Self test type	<ul style="list-style-type: none"><li>• CMDTC self test, KOER self test</li></ul>
	Sensor used	<ul style="list-style-type: none"><li>• A/F sensor</li></ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"><li>• Fixes duty value of A/F sensor heater</li><li>• Stops fuel feedback control of A/F sensor</li></ul>	
<b>VEHICLE STATUS WHEN DTCs ARE OUTPUT</b>	<ul style="list-style-type: none"><li>• Illuminates check engine light.</li></ul>	
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• A/F sensor connector or terminals malfunction</li><li>• PCM connector or terminals malfunction</li><li>• Short to power supply in wiring harness between the following terminals:<ul style="list-style-type: none"><li>— A/F sensor terminal F—PCM terminal 1W</li><li>— A/F sensor terminal D—PCM terminal 1AB</li><li>— A/F sensor terminal B—PCM terminal 1AG</li></ul></li><li>• A/F sensor malfunction</li><li>• PCM malfunction</li></ul>	

## System Wiring Diagram



am6xuw00006284

### Function Explanation (DTC Detection Outline)

- If any of the following conditions is detected, the PCM determines a short to the power supply between the A/F sensor terminal and the PCM terminal and stores a DTC.
  - Voltage of A/F sensor terminal F is above specified value
  - Voltage of A/F sensor terminal D is above specified value
  - Voltage of A/F sensor terminal B is above specified value

### Repeatability Verification Procedure

- Start the engine and leave it idling for **1 min**.

### PID Item/Simulation Item Used In Diagnosis

#### PID/DATA monitor item table

Item	Definition	Unit/ Condition	Condition/Specification (Reference)
O2S11	A/F sensor	μA	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. -39 μA</li> <li>Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 3.84 mA</li> </ul>

## Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	<b>PURPOSE: VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
2	<b>PURPOSE: RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes	Go to the troubleshooting procedure to perform the procedure from Step 1.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order.  <b>Note</b> <ul style="list-style-type: none"> <li>Recording can be facilitated using the screen capture function of the PC.</li> </ul> Go to the troubleshooting procedure to perform the procedure from Step 1.

## Troubleshooting Diagnostic Procedure

### Intention of troubleshooting procedure

- Step 1—2
  - Perform an inspection of the A/F sensor and PCM-related connectors.
- Step 3
  - Perform an inspection of the short to power supply in wiring harness between A/F sensor and PCM.
- Step 4
  - Perform a unit inspection of the A/F sensor.
- Step 5—6
  - Verify that the primary malfunction is resolved and there are no other malfunctions.

STEP	INSPECTION	RESULTS	ACTION
1	<b>PURPOSE: INSPECT A/F SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the A/F sensor connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 5.
		No	Go to the next step.
2	<b>PURPOSE: INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 5.
		No	Go to the next step.
3	<b>PURPOSE: INSPECT A/F SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>Verify that the A/F sensor and PCM connectors are disconnected.</li> <li>Switch the ignition ON (engine off).</li> <li>Measure the voltage at the following terminals (wiring harness-side):               <ul style="list-style-type: none"> <li>— A/F sensor terminal F</li> <li>— A/F sensor terminal D</li> <li>— A/F sensor terminal B</li> </ul> </li> <li>Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• A/F sensor terminal F—PCM terminal 1W</li> <li>• A/F sensor terminal D—PCM terminal 1AB</li> <li>• A/F sensor terminal B—PCM terminal 1AG</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to power supply.</li> </ul> Go to Step 5.

STEP	INSPECTION	RESULTS	ACTION
4	<b>PURPOSE: DETERMINE INTEGRITY OF A/F SENSOR</b> <ul style="list-style-type: none"> <li>Start the engine and warm it up completely.</li> <li>Access the O2S11 PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Drive the vehicle under the following conditions.               <div> <b>Warning</b> <ul style="list-style-type: none"> <li>When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later.</li> <li>While performing this step, always operate the vehicle in a safe and lawful manner.                   <ul style="list-style-type: none"> <li>After increasing the engine speed to <b>3,000 rpm</b>, decelerate using engine braking.</li> </ul> </li> </ul> </div></li> <li>Is the displayed PID value as follows?               <ul style="list-style-type: none"> <li>O2S11: <b>0.25 mA or more</b></li> </ul> </li> </ul>	Yes	Go to the next step.
		No	Replace the A/F sensor, then go to the next step. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
5	<b>PURPOSE: VERIFICATION OF VEHICLE REPAIR COMPLETION</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is the PENDING CODE for this DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul> Go to the next step.
		No	Go to the next step.
6	<b>PURPOSE: VERIFY IF THERE IS ANY OTHER MALFUNCTION</b> <ul style="list-style-type: none"> <li>Is any other DTC or pending code stored?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.