

SYMPTOM TROUBLESHOOTING CHART [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)]

id0903608056j5

No.	Troubleshooting item	page
1	The auto open/close function on the driver-side power window is inoperative	THE AUTO OPEN/CLOSE FUNCTION ON THE DRIVER-SIDE POWER WINDOW IS INOPERATIVE [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]
2	The driver-side power window is inoperative	THE DRIVER-SIDE POWER WINDOW IS INOPERATIVE [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]
3	All power windows other than driver-side do not operate using the power window subswitch	ALL POWER WINDOWS OTHER THAN DRIVER-SIDE DO NOT OPERATE USING THE POWER WINDOW SUBSWITCH [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]
4	All power windows other than driver-side do not operate using the power window main switch	ALL POWER WINDOWS OTHER THAN DRIVER-SIDE DO NOT OPERATE USING THE POWER WINDOW MAIN SWITCH [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]
5	All power windows are inoperative	ALL POWER WINDOWS ARE INOPERATIVE [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]
6	Door glass reverses even though the glass does not encounter a foreign object while it is moving up in automatic mode	DOOR GLASS REVERSES EVEN THOUGH THE GLASS DOES NOT ENCOUNTER A FOREIGN OBJECT WHILE IT IS MOVING UP IN AUTOMATIC MODE [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]
7	Abnormal noise while the door glass is opening or closing	ABNORMAL NOISE WHILE THE DOOR GLASS IS OPENING OR CLOSING [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]