

---

## FUEL TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0140z7806500

### Note

- The fuel temperature sensor cannot be removed as a single unit. When replacing the fuel temperature sensor, replace it together with the lower case as a single unit.

1. Remove the lower case. (See LOWER CASE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)