



1	Intake manifold (See INTAKE-AIR SYSTEM REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].)
---	---

2	Glow plug (See GLOW PLUG REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See GLOW PLUG INSPECTION [SKYACTIV-D 2.2].)
3	Fresh-air duct (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
4	Vacuum chamber (See VACUUM CHAMBER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See VACUUM CHAMBER INSPECTION [SKYACTIV-D 2.2].)
5	Turbocharger (See TURBOCHARGER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See TURBOCHARGER INSPECTION [SKYACTIV-D 2.2].)
6	Glow control module (See GLOW PLUG CONTROL MODULE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See GLOW PLUG CONTROL MODULE INSPECTION [SKYACTIV-D 2.2].)
7	Check valve (See CHECK VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See CHECK VALVE INSPECTION [SKYACTIV-D 2.2].)
8	Air cleaner (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See AIR CLEANER ELEMENT INSPECTION [SKYACTIV-D 2.2].)

9	Resonance chamber (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
10	Charge air cooler (See CHARGE AIR COOLER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See CHARGE AIR COOLER INSPECTION [SKYACTIV-D 2.2].)
11	Regulating solenoid valve (See REGULATING SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See REGULATING SOLENOID VALVE INSPECTION [SKYACTIV-D 2.2].)
12	Wastegate solenoid valve (See WASTEGATE SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See WASTEGATE SOLENOID VALVE INSPECTION [SKYACTIV-D 2.2].)
13	Compressor bypass solenoid valve (See COMPRESSOR BYPASS SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See COMPRESSOR BYPASS SOLENOID VALVE INSPECTION [SKYACTIV-D 2.2].)
14	Accelerator pedal (See ACCELERATOR PEDAL REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)