


ELECTRONIC 4WD CONTROL SYSTEM LOCATION INDEX

id031800805200



ac5wzw00002632

| | |
|---|---|
| 1 | Differential oil temperature sensor (See DIFFERENTIAL OIL TEMPERATURE SENSOR INSPECTION.) (See DIFFERENTIAL OIL TEMPERATURE SENSOR REMOVAL/INSTALLATION.) |
| 2 | 4WD solenoid (See 4WD SOLENOID INSPECTION.) |
| 3 | 4WD control module (See 4WD CONTROL MODULE INSPECTION.) (See 4WD CONTROL MODULE REMOVAL/ INSTALLATION.) (See 4WD CONTROL MODULE CONFIGURATION.) (See COUPLING COMPONENT CALIBRATION DATA WRITING.) |

| | |
|---|--|
| 4 | Coupling component (See COUPLING COMPONENT REMOVAL/ INSTALLATION.) |
|---|--|