

DTC B13C3:16 [ADVANCED KEYLESS ENTRY SYSTEM]

id0902p8027100

System malfunction location	LF control unit power supply voltage decrease input
Detection condition	<ul style="list-style-type: none"> With the ignition switched ON (engine off), start stop unit power supply circuit (+B1) voltage of 8.5 V or more or less than 16.5 V and LF control unit power supply circuit voltage of 5 V or more or less than 8.5 V are detected for 5 s or more.
Fail-safe	<ul style="list-style-type: none"> Inhibits the door lock/unlock control using the advanced keyless entry system.
Possible cause	<ul style="list-style-type: none"> LF control unit connector or terminal malfunction LF control unit power supply circuit malfunction <ul style="list-style-type: none"> Short to ground in the wiring harness between ROOM 15 A fuse and LF control unit terminal A ROOM 15 A fuse malfunction Open circuit in wiring harness between battery positive terminal and LF control unit terminal A LF control unit malfunction Start stop unit malfunction

AA	Y	W	U	S	Q	O	M	K	I	G	E	C	A
AB	Z	X	V	T	R	P	N	L	J	H	F	D	B

Diagnostic Procedure

Step	Inspection	Action
1	INSPECT LF CONTROL UNIT CONNECTOR CONDITION <ul style="list-style-type: none">• Switch the ignition to off.• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)• Disconnect the LF control unit connector.• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.• Is the connector normal?	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 4.

Step	Inspection	Action
2	INSPECT LF CONTROL UNIT POWER SUPPLY CIRCUIT <ul style="list-style-type: none"> • Verify that the LF control unit connector is disconnected. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Measure the voltage at LF control unit terminal A (vehicle wiring harness side). • Is the voltage B+? 	Yes Go to the next step.
		No Inspect the ROOM 15 A fuse. <ul style="list-style-type: none"> • If a fuse is burnt out: <ul style="list-style-type: none"> — Repair or replace the wiring harness which is shorted to ground. — Replace the fuse. • If a fuse is damaged: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness which has an open circuit. Go to Step 4.
3	INSPECT LF CONTROL UNIT <ul style="list-style-type: none"> • Inspect the LF control unit. (See LF CONTROL UNIT INSPECTION.) • Is the LF control unit normal? 	Yes Go to the next step.
		No Replace the LF control unit, then go to the next step. (See LF CONTROL UNIT REMOVAL/INSTALLATION.)
4	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear DTCs for the advanced keyless entry system using the M-MDS. (See CLEARING DTC [ADVANCED KEYLESS ENTRY SYSTEM].) • Switch the ignition ON (engine off) and wait for 5 s or more. • Perform the advanced keyless entry system DTC inspection using the M-MDS. (See DTC INSPECTION [ADVANCED KEYLESS ENTRY SYSTEM].) • Is DTC B13C3:16 displayed? 	Yes Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
5	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ADVANCED KEYLESS ENTRY SYSTEM].)
		No DTC troubleshooting completed.