

NO.8 ENGINE RUNS ROUGH/ROLLING IDLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0103g3801400

8	ENGINE RUNS ROUGH/ROLLING IDLE
DESCRIPTION	<ul style="list-style-type: none"> • Engine speed fluctuates between specified idle speed and lower speed and, engine shakes excessively. • Idle speed is too slow and engine shakes excessively.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Engine overheating • PCM DTC is stored • Erratic signal to PCM <ul style="list-style-type: none"> — APP sensor or related circuit malfunction — ECT sensor or related circuit malfunction — MAF sensor or related circuit malfunction — MAP sensor or related circuit malfunction — A/F sensor or related circuit malfunction — HO2S or related circuit malfunction — Improper air/fuel mixture ratio control operation • Improper load signal input <ul style="list-style-type: none"> — Improper A/C request signal • Improper operation of A/C system • Improper operation of drive-by-wire control system • Incorrect fuel injection timing • Unbalanced fuel injection amount for each cylinder • Purge solenoid valve malfunction • Poor fuel quality • Air leakage from intake-air system • Intake-air system restriction • Electrical connector disconnected • Fuel leakage • Vacuum leakage • Improper engine oil viscosity • Erratic or no signal from CMP sensor <ul style="list-style-type: none"> — Loose installation — Damaged trigger wheel (intake camshaft and/or exhaust camshaft) — Open or short circuit in related wiring harness • Erratic signal from CKP sensor <ul style="list-style-type: none"> — Loose installation — Damaged trigger wheel (crankshaft pulley) — Open or short circuit in related wiring harness • Inadequate fuel pressure (high or low pressure side) <ul style="list-style-type: none"> — Fuel pressure sensor or related circuit malfunction — High pressure fuel pump malfunction — Spill valve control solenoid valve control circuit malfunction (damage to driver in PCM caused by short circuit to ground system) — Spill valve control solenoid valve (built-into high pressure fuel pump) malfunction — Relief valve (built-into high pressure fuel pump) malfunction — Fuel pump (low-side) body mechanical malfunction — Fuel filter clogged — Fuel injector malfunction • Improper operation of electric variable valve timing control system (PCM DTC is stored.) • Improper operation of hydraulic variable valve timing control system • Low engine compression or excessive unbalance for each cylinder • Improper intake valve timing • Improper exhaust valve timing • Spark plug malfunction • Incorrect signal to ignition coil • Exhaust system or TWC restricted • PCV valve malfunction • Injector driver (built-into PCM) malfunction

8	ENGINE RUNS ROUGH/ROLLING IDLE
POSSIBLE CAUSE	<p>Warning The following troubleshooting flow chart contains the fuel system diagnosis and repair procedures. Read the following warnings before performing the fuel system services:</p> <ul style="list-style-type: none"> Fuel vapor is hazardous. It can easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel. Fuel line spills and leakage are dangerous. Fuel can ignite and cause serious injury or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete “BEFORE SERVICE PRECAUTION” and “AFTER SERVICE PRECAUTION” described in this manual. (See BEFORE SERVICE PRECAUTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See AFTER SERVICE PRECAUTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) <p>Caution • Disconnecting/connecting the quick release connector without cleaning it may possibly cause damage to the fuel pipe and quick release connector. Always clean the quick release connector joint area before disconnecting/connecting, and make sure that it is free of foreign matter.</p>

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	VERIFY IF MALFUNCTION INCLUDES HARD ENGINE STARTING <ul style="list-style-type: none"> Verify the vehicle engine condition. Can idling be maintained? 	Yes	Go to the next step.
		No	Perform the symptom troubleshooting “NO.5 ENGINE STALLS-AFTER START/AT IDLE”. (See NO.5 ENGINE STALLS-AFTER START/AT IDLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
2	VERIFY IF MALFUNCTION CAUSE IS OVERHEATING <p>Caution</p> <ul style="list-style-type: none"> While performing this step, always operate the vehicle in a safe and lawful manner. When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later. <ul style="list-style-type: none"> Access the ECT PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is the ECT PID value less than 116 °C {241 ° F} during driving? 	Yes	Go to the next step.
		No	The cause of this concern could be from the cooling system overheating. <ul style="list-style-type: none"> Perform the symptom troubleshooting “NO.17 COOLING SYSTEM CONCERNS-OVERHEATING”. (See NO.17 COOLING SYSTEM CONCERNS-OVERHEATING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
3	VERIFY PCM DTC <ul style="list-style-type: none"> Retrieve any DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
4	VERIFY CURRENT INPUT SIGNAL STATUS Caution <ul style="list-style-type: none"> • While performing this step, always operate the vehicle in a safe and lawful manner. • When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later. <ul style="list-style-type: none"> • Access the following PIDs using the M-MDS: (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) <ul style="list-style-type: none"> — APP1 — APP2 — ECT — MAF — MAP — O2S11 — O2S12 — SHRTFT1 — LONGFT1 • Do the PIDs indicate the correct values under the malfunction condition? (See PCM INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) 	Yes	Go to the next step.
		No	APP1, APP2 PIDs are not as specified: <ul style="list-style-type: none"> • Inspect the APP sensor. (See ACCELERATOR PEDAL POSITION (APP) SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) ECT PID is not as specified: <ul style="list-style-type: none"> • Inspect the ECT sensor. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) MAF PID is not as specified: <ul style="list-style-type: none"> • Inspect the MAF sensor. (See MASS AIR FLOW (MAF) SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) MAP PID is not as specified: <ul style="list-style-type: none"> • Inspect the MAP sensor. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) O2S11, SHRTFT1, LONGFT1 PIDs are not as specified: <ul style="list-style-type: none"> • Inspect the A/F sensor. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) O2S12 PID is not as specified: <ul style="list-style-type: none"> • Inspect the HO2S. (See HEATED OXYGEN SENSOR (HO2S) INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Repair or replace the malfunctioning part according to the inspection results. <ul style="list-style-type: none"> • If the malfunction remains: <ul style="list-style-type: none"> — Perform the “INTERMITTENT CONCERN TROUBLESHOOTING” procedure. (See INTERMITTENT CONCERN TROUBLESHOOTING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
5	DETERMINE IF MALFUNCTION CAUSE IS A/C REQUEST SIGNAL OR OTHER <ul style="list-style-type: none"> • Access the AC_REQ PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Monitor the AC_REQ PID while turning on and off the air conditioner using the switch on the control panel. • Does the AC_REQ PID value change from on to off according to switch control panel? 	Yes	Go to the next step.
		No	If the AC_REQ PID is always ON: <ul style="list-style-type: none"> • Perform the symptom troubleshooting “NO.24 A/C IS ALWAYS ON OR A/C COMPRESSOR RUNS CONTINUOUSLY”. (See NO.24 A/C IS ALWAYS ON OR A/C COMPRESSOR RUNS CONTINUOUSLY [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) If the AC_REQ PID is always OFF: <ul style="list-style-type: none"> • Perform the symptom troubleshooting “NO.23 A/C DOES NOT WORK SUFFICIENTLY”. (See NO.23 A/C DOES NOT WORK SUFFICIENTLY [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
6	INSPECT A/C CUT-OFF CONTROL SYSTEM OPERATION <ul style="list-style-type: none"> • Perform the A/C Cut-off Control System Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Does the A/C cut-off operation work properly? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.

STEP	INSPECTION	RESULTS	ACTION
7	INSPECT DRIVE-BY-WIRE CONTROL SYSTEM OPERATION <ul style="list-style-type: none"> Perform the TP sweep inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Does the drive-by-wire control system work properly? 	Yes	Visually inspect the throttle body (damage/scratching). <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
8	INSPECT FUEL INJECTOR OPERATION <ul style="list-style-type: none"> Perform the Fuel Injector Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Do the fuel injectors operate properly? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
9	INSPECT PURGE CONTROL SYSTEM OPERATION <ul style="list-style-type: none"> Perform the Purge Control System Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Does the purge solenoid valve work properly? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
10	INSPECT RELATED PART CONDITION <ul style="list-style-type: none"> Inspect the following: <ul style="list-style-type: none"> Fuel quality (proper octane, contamination, winter/summer blend) Intake-air system restriction or leakage Electrical connectors connection Fuel leakage in fuel system Vacuum leakage Engine oil viscosity CKP sensor, intake CMP sensor and exhaust CMP sensor Installation condition (See CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See CAMSHAFT POSITION (CMP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Damaged trigger wheel, intake camshaft and exhaust camshaft Is there any malfunction? 	Yes	Service if necessary. <ul style="list-style-type: none"> Repeat this step.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
11	INSPECT FUEL PRESSURE (HIGH-SIDE) <ul style="list-style-type: none"> Start the engine and warm it up completely. Access the FUEL_PRES PID using the M-MDS at idle. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is the FUEL_PRES PID value approx. 3 MPa {31 kgf/cm², 435 psi}? 	Yes	Go to Step 15.
		No	Lower than 3 MPa {31 kgf/cm², 435 psi} : <ul style="list-style-type: none"> Inspect the following: <ul style="list-style-type: none"> Fuel leakage at the fuel line and fuel injector Fuel pump <ul style="list-style-type: none"> Perform the Fuel Pump (Low-pressure Side) Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Fuel pressure sensor (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) High pressure fuel pump (See HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Go to Step 14. Higher than 3 MPa {31 kgf/cm², 435 psi} : <ul style="list-style-type: none"> Go to the next step.
12	DETERMINE IF MALFUNCTION CAUSE IS FUEL PRESSURE SENSOR OR HIGH PRESSURE FUEL PUMP <ul style="list-style-type: none"> Is the vehicle acceleration performance normal? 	Yes	Go to the next step.
		No	Go to Step 14.
13	INSPECT FUEL PRESSURE SENSOR <ul style="list-style-type: none"> Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there any malfunction? 	Yes	Replace the fuel distributor. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to Step 15.
14	INSPECT SPILL VALVE CONTROL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Switch the ignition off. Disconnect the high pressure fuel pump and PCM connectors. Inspect for continuity between high pressure fuel pump terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground. <ul style="list-style-type: none"> If the malfunction remains: <ul style="list-style-type: none"> Replace the PCM. (damage to driver in PCM) (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Replace the high pressure fuel pump. (See HIGH PRESSURE FUEL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
15	INSPECT FUEL PRESSURE (LOW-SIDE) <ul style="list-style-type: none"> Connect the fuel pressure gauge between fuel pump and high pressure fuel pump. Measure the low side fuel pressure. (See FUEL LINE PRESSURE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is the low side fuel pressure within specification? Specification: 405—485 kPa {4.13—4.94 kgf/cm², 58.8—70.3 psi} 	Yes	Go to the next step.
		No	Inspect the following: <ul style="list-style-type: none"> Fuel line restriction Fuel filter clogged <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Replace the fuel pump unit. (See FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)

STEP	INSPECTION	RESULTS	ACTION
16	INSPECT HYDRAULIC VARIABLE VALVE TIMING CONTROL SYSTEM OPERATION <ul style="list-style-type: none"> Perform the Hydraulic Variable Valve Timing Control System Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Does the hydraulic variable valve timing control system work properly? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
17	INSPECT ENGINE COMPRESSION <ul style="list-style-type: none"> Measure the compression pressure for each cylinder. (See COMPRESSION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Are compression pressures within specification? Specification: <ul style="list-style-type: none"> Compression [SKYACTIV-G 2.0, European (L.H.D. U.K.) specs.] <ul style="list-style-type: none"> Standard: 978 kPa {9.97 kgf/cm², 142 psi} (300 rpm) Minimum: 783 kPa {7.98 kgf/cm², 114 psi} (300 rpm) Maximum difference between cylinders: 166 kPa {1.69 kgf/cm², 24.1 psi} (300 rpm) Compression [SKYACTIV-G 2.0, Except European (L.H.D. U.K.) specs.] <ul style="list-style-type: none"> Standard: 885 kPa {9.02 kgf/cm², 128 psi} (300 rpm) Minimum: 708 kPa {7.22 kgf/cm², 103 psi} (300 rpm) Maximum difference between cylinders: 150 kPa {1.53 kgf/cm², 21.8 psi} (300 rpm) Compression [SKYACTIV-G 2.5] <ul style="list-style-type: none"> Standard: 954 kPa {9.73 kgf/cm², 138 psi} (300 rpm) Minimum: 763 kPa {7.78 kgf/cm², 111 psi} (300 rpm) Maximum difference between cylinders: 161 kPa {1.64 kgf/cm², 23.4 psi} (300 rpm) Note <ul style="list-style-type: none"> Because the SKYACTIV-G 2.0 and SKYACTIV-G 2.5 retards the intake valve closing timing, compression pressure is low. 	Yes	Go to the next step.
		No	Inspect the following: <ul style="list-style-type: none"> Damaged valve seat Worn valve stem and valve guide Worn or stuck piston ring Worn piston, piston ring or cylinder Improper intake valve timing Improper exhaust valve timing Service if necessary.
18	INSPECT IGNITION SYSTEM OPERATION <ul style="list-style-type: none"> Perform the Spark Test. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is a strong blue spark visible at each cylinder? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
19	INSPECT EXHAUST SYSTEM FOR RESTRICTION <ul style="list-style-type: none"> Inspect for restriction in the exhaust system and the TWC. Is there any restriction? 	Yes	Repair or replace the malfunctioning part according to the inspection results.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
20	INSPECT IF MALFUNCTION CAUSE IS PCV VALVE OR INJECTOR DRIVER (PCM INTEGRATED) <ul style="list-style-type: none"> Inspect the PCV valve. (See POSITIVE CRANKCASE VENTILATION (PCV) VALVE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there any malfunction? 	Yes	Replace the PCV valve. (See POSITIVE CRANKCASE VENTILATION (PCV) VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Injector driver malfunction. <ul style="list-style-type: none"> Replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) If the problem remains, overhaul the engine.
21	Verify the test results. <ul style="list-style-type: none"> If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis. <ul style="list-style-type: none"> If the vehicle is repaired, troubleshooting is completed. If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) 		