

DTC P2135:00 [SKYACTIV-G 2.0]

id0102h1708700

DTC P2135:00	TP sensor No.1/No.2 voltage correlation problem
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM compares the input voltage from TP sensor No.1 with the input voltage from TP sensor No.2. If the difference is more than the specification, the PCM determines that there is a TP sensor No.1/No.2 voltage correlation problem. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Restricts the upper limit of the engine speed. Stops the drive-by-wire control (throttle valve is open at approx. 8 ° by return spring force).
POSSIBLE CAUSE	<ul style="list-style-type: none"> Throttle body connector or terminals malfunction PCM connector or terminals malfunction TP sensor No.1 malfunction TP sensor No.2 malfunction PCM malfunction
SYSTEM WIRING DIAGRAM	—

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC • Switch the ignition to off, then to ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) • Is the PENDING CODE/DTC P0122:00, P0123:00, P0222:00 or P0223:00 also present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC P0122:00 [SKYACTIV-G 2.0].) (See DTC P0123:00 [SKYACTIV-G 2.0].) (See DTC P0222:00 [SKYACTIV-G 2.0].) (See DTC P0223:00 [SKYACTIV-G 2.0].)
		No	Go to the next step.
4	INSPECT THROTTLE BODY CONNECTOR CONDITION • Switch the ignition to off. • Disconnect the throttle body connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
6	INSPECT TP SENSOR NO.1 AND NO.2 • Reconnect all disconnected connectors. • Inspect the TP sensor No.1 and No.2. (See THROTTLE POSITION (TP) SENSOR INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction?	Yes	Replace the throttle body, then go to the next step. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Intermittent concern exists. • Perform the "INTERMITTENT CONCERN TROUBLESHOOTING" procedure. (See INTERMITTENT CONCERN TROUBLESHOOTING [SKYACTIV-G 2.0].)

STEP	INSPECTION	ACTION	
7	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Start the engine. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.