

ATF SEEPING FROM AUTOMATIC TRANSAXLE [GW6A-EL, GW6AX-EL]

id050320103800

TROUBLESHOOTING ITEM	ATF seeping from automatic transaxle
DESCRIPTION	<ul style="list-style-type: none"> • ATF is seeping from the automatic transaxle case. • Foreign matter mixed with ATF is in the automatic transaxle case.
POSSIBLE CAUSE	<p>Note</p> <ul style="list-style-type: none"> • ATF seeping radiates from ATF leak source. • Identify the type of seeping oil referring to “SERVICE CAUTIONS, Oil Leakage Inspection” in the general information. (See SERVICE CAUTIONS.) • To prevent misdiagnosis, remove any grease or dirt from the seep location and verify the location of the seeping after driving the vehicle. <ul style="list-style-type: none"> • ATF leakage from the following locations <ul style="list-style-type: none"> — Oil pan (Part of drain plug etc.) — Converter housing (Part of torque converter etc.) — End cover — Oil cooler — Oil seal (differential) — Oil seal (control valve body) — Oil seal (manual shaft) — Dipstick — Line pressure detection port — Air breather

Diagnostic procedure

STEP	INSPECTION		ACTION
1	VERIFY IF THE MALFUNCTION CAUSE IS ATF LEAKAGE FROM THE FOLLOWING LOCATIONS <ul style="list-style-type: none"> • Verify if ATF is leaking from the locations described above. • Is there ATF seeping from a location? 	Yes	Verify the installation and damage condition of the part at the location where the ATF is seeping and repair or replace the malfunctioning part.
		No	Symptom troubleshooting is completed.