

DTC U2100:00 [REAR BODY CONTROL MODULE (RBCM)]

id0902p4015400

System malfunction location	Rear body control module (RBCM) configuration error
Detection condition	• Rear body control module (RBCM) configuration error detected.
Fail-safe	—
Possible cause	• Rear body control module (RBCM) configuration error • Rear body control module (RBCM) malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	VERIFY REAR BODY CONTROL MODULE (RBCM) DTCs AGAIN <ul style="list-style-type: none">• Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].)• Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)• Is DTC U2100:00 displayed?	Yes Go to the next step.
		No Go to Step 4.
2	PERFORM REAR BODY CONTROL MODULE (RBCM) CONFIGURATION (USING AS-BUILT DATA) <ul style="list-style-type: none">• Using the M-MDS, perform the rear body control module (RBCM) configuration with the As-Built data. (See REAR BODY CONTROL MODULE (RBCM) CONFIGURATION (USING AS-BUILT DATA).)• Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].)• Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)• Is DTC U2100:00 displayed?	Yes Using the M-MDS, re-perform the rear body control module (RBCM) configuration using the As-Built data, then go to the next step. (See REAR BODY CONTROL MODULE (RBCM) CONFIGURATION (USING AS-BUILT DATA).)
		No Go to Step 4.
3	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none">• Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].)• Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].)• Is DTC U2100:00 displayed?	Yes Replace the rear body control module (RBCM), then go to the next step. (See REAR BODY CONTROL MODULE (RBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
4	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)].)
		No DTC troubleshooting completed.