


DTC U0338:00	Start stop unit error
DETECTION CONDITION	<ul style="list-style-type: none">• When any of the following conditions is met:<ul style="list-style-type: none">— CAN communication line malfunction between PCM and start stop unit— Start stop unit internal malfunction Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (other).• The check engine light does not illuminate.• FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none">• CAN drive error (instrument cluster or PCM)• CAN communication line malfunction between PCM and start stop unit<ul style="list-style-type: none">— Start stop unit terminal 2M—Front body control module (FBCM) terminal 2K— Start stop unit terminal 2O—Front body control module (FBCM) terminal 2I— Front body control module (FBCM) terminal 2P—PCM terminal 2AK— Front body control module (FBCM) terminal 2N—PCM terminal 2AL• Front body control module (FBCM) malfunction• Start stop unit connector or terminals malfunction• PCM connector or terminals malfunction• Start stop unit malfunction• PCM malfunction


⑦

START STOP UNIT




START STOP UNIT
WIRING HARNESS-SIDE
CONNECTOR

2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A
2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B




FBCM




FBCM
WIRING HARNESS-SIDE
CONNECTOR

2AA	2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A
2AB	2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B



PCM WIRING HARNESS-SIDE CONNECTOR

2BE	2AZ	2AU	2AP	2AK	2AE	2AA	2W	2S	2O	2K	2G	2C		
2BF	2BA	2AV	2AQ	2AL	2AF	2AB	2X	2T	2P	2L	2H	2D		
2BG	2BB	2AW	2AR	2AM										
2BH	2BC	2AX	2AS	2AN	2AI	2AG	2AC	2Y	2U	2Q	2M	2I	2E	2A
	2BD	2AY	2AT	2AO	2AJ	2AH	2AD	2Z	2V	2R	2N	2J	2F	2B



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	VERIFY DTC FOR MODULE COMMUNICATION <ul style="list-style-type: none"> • Switch the ignition off, then ON (engine off). • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
3	VERIFY FRONT BODY CONTROL MODULE (FBCM) DTC <ul style="list-style-type: none"> • Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	Go to the next step.
4	VERIFY START STOP UNIT DTC <ul style="list-style-type: none"> • Perform the start stop unit DTC inspection using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [START STOP UNIT].)
		No	Go to the next step.
5	VERIFY INSTRUMENT CLUSTER DTC <ul style="list-style-type: none"> • Perform the instrument cluster DTC inspection using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
6	INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the start stop unit connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
7	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to the next step.
		No	CAN communication line can be considered the cause. <ul style="list-style-type: none"> • Repair or replace the following wiring harnesses. <ul style="list-style-type: none"> — Start stop unit terminal 2M—Front body control module (FBCM) terminal 2K — Start stop unit terminal 2O—Front body control module (FBCM) terminal 2I — Front body control module (FBCM) terminal 2P—PCM terminal 2AK — Front body control module (FBCM) terminal 2N—PCM terminal 2AL • If the malfunction recurs, replace the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION.) Go to the next step.

STEP	INSPECTION	ACTION	
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.