


Warning

- **A hot engine and intake air system can cause severe burns. Turn off the engine and wait until they are cool before removing the intake air system.**

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0 (WITHOUT i-stop)].)
2. Remove in the order indicated in the table.
3. Install in the reverse order of removal.



ac5wzw00002698

1	Ventilation hose (See Ventilation Hose Installation Note.)
2	Resonance chamber (See Resonance Chamber Removal Note.)
3	Air hose (See Air Hose Installation Note.)
4	Air cleaner cover

5	Air cleaner element
6	Fresh-air duct (See Fresh-air Duct Removal Note.) (See Fresh-air Duct Installation Note.)
7	Air cleaner case (See Air Cleaner Case Installation Note.)
8	Throttle body

9	Vacuum hose (See Vacuum Hose Removal Note.) (See Vacuum Hose Installation Note.)
10	Evaporative hose (See Evaporative Hose Installation Note)


11	PCV hose
12	Intake manifold (See Intake Manifold Removal Note)

Resonance Chamber Removal Note

1. Remove the MAF sensor/IAT sensor No.1. (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
2. Remove the following parts as a single unit:
 - Air hose
 - Air cleaner cover
 - Air cleaner element
 - Air cleaner case
 - Fresh-air duct
 - Resonance chamber
3. Remove the resonance chamber.

Fresh-air Duct Removal Note

1. Pull out the fresh-air duct while pressing the tab shown in the figure.




ac5uuw00000365

Vacuum Hose Removal Note

1. Remove the plug hole plate. (See PLUG HOLE PLATE REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
2. Remove the vacuum hose.

Intake Manifold Removal Note

1. Remove the MAP sensor/IAT sensor No.2. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
2. Disconnect the harness clip from the intake manifold as shown in the figure.




ac5uuw00000366

3. Remove the intake manifold.

Evaporative Hose Installation Note


1. Install the evaporative hose as shown in the figure.



ac5wzw00002699

Vacuum Hose Installation Note


1. Install the vacuum hose as shown in the figure.



ac5wzw00002700

Air Cleaner Case Installation Note


1. Install the air cleaner case as shown in the figure.



ac5uww00000367

Fresh-air Duct Installation Note

1. Install the fresh-air duct as shown in the figure.




ac5uuw00000368

Air Hose Installation Note


1. Install the air hose as shown in the figure.

Throttle body side



ac5wzw00002701

Air cleaner side




ac5wzw00002702

Ventilation Hose Installation Note


1. Install the ventilation hose as shown in the figure.

Cylinder head cover side



am3uuw00008002

Air hose side



ac5uuw00000371