


Caution

- **Perform the following malfunction diagnosis only when it is diagnosed with a short to ground by CONTROLLER AREA NETWORK (CAN) MALFUNCTION DIAGNOSIS FLOW [SKYACTIV-G 2.0 (R.H.D.)].**

System wiring diagram



Determination procedure

Caution

- When disconnecting the connector, verify that there is no looseness, damage, deformation, corrosion, or poor connection of the connector terminals.
- When inspecting the DLC-2, touch it with a paper clip or similar thin pin without directly inserting a tester into the terminals.

| Step | Inspection | Action |
|------|---|--|
| 1 | INSPECT FOR SHORT TO GROUND BETWEEN FRONT BODY CONTROL MODULE (FBCM) AND INSTRUMENT CLUSTER <ul style="list-style-type: none"> • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0].) • (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0 (WITHOUT i-stop)].) • Disconnect connector 2 which has front body control module (FBCM) terminals 2P and 2N. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between DLC-2 terminal F and body ground — Between DLC-2 terminal E and body ground • Is there continuity? | Yes Go to Step 5. |
| | | No Go to the next step. |
| 2 | INSPECT CAN LINE INSIDE FRONT BODY CONTROL MODULE (FBCM) FOR SHORT TO GROUND <ul style="list-style-type: none"> • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between front body control module (FBCM) terminal 2P and body ground — Between front body control module (FBCM) terminal 2N and body ground • Is there continuity? | Yes Replace the front body control module (FBCM) because there is a short to ground in the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.) |
| | | No Go to the next step. |
| 3 | INSPECT FOR SHORT TO GROUND BETWEEN AFS CONTROL MODULE AND FRONT BODY CONTROL MODULE (FBCM) <ul style="list-style-type: none"> • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between AFS control module terminal A and body ground — Between AFS control module terminal B and body ground • Is there continuity? | Yes Go to the next step. |
| | | No Go to Step 26. |
| 4 | INSPECT CAN LINE IN AFS CONTROL MODULE FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the AFS control module connector. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between AFS control module terminal A (wiring harness side) and body ground — Between AFS control module terminal B (wiring harness side) and body ground • Is there continuity? | Yes Repair or replace the wiring harness between the AFS control module and front body control module (FBCM) because the wiring harness is shorted to ground. |
| | | No Replace the AFS control module because there is a short to ground in the AFS control module. (See ADAPTIVE FRONT LIGHTING SYSTEM (AFS) CONTROL MODULE REMOVAL/INSTALLATION.) |

| Step | Inspection | Action |
|------|--|--------|
| 5 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-04 AND INSTRUMENT CLUSTER <ul style="list-style-type: none"> • Disconnect connector C-04. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between DLC-2 terminal F and body ground — Between DLC-2 terminal E and body ground • Is there continuity? | Yes |
| | | No |
| 6 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTORS C-49 AND C-50 AND INSTRUMENT CLUSTER <ul style="list-style-type: none"> • Disconnect connectors C-49 and C-50. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between DLC-2 terminal F and body ground — Between DLC-2 terminal E and body ground • Is there continuity? | Yes |
| | | No |
| 7 | INSPECT FOR SHORT TO GROUND BETWEEN 4WD CONTROL MODULE AND CONNECTORS C-49 AND C-50 <ul style="list-style-type: none"> • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between 4WD control module terminal G and body ground — Between 4WD control module terminal H and body ground • Is there continuity? | Yes |
| | | No |
| 8 | INSPECT CAN LINE IN 4WD CONTROL MODULE FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the 4WD control module connector. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between 4WD control module terminal G (wiring harness side) and body ground — Between 4WD control module terminal H (wiring harness side) and body ground • Is there continuity? | Yes |
| | | No |
| 9 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-10 AND INSTRUMENT CLUSTER <ul style="list-style-type: none"> • Disconnect connector C-10. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between DLC-2 terminal F and body ground — Between DLC-2 terminal E and body ground • Is there continuity? | Yes |
| | | No |
| 10 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-11 AND INSTRUMENT CLUSTER <ul style="list-style-type: none"> • Disconnect connector C-11. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between DLC-2 terminal F and body ground — Between DLC-2 terminal E and body ground • Is there continuity? | Yes |
| | | No |

| Step | Inspection | Action | |
|------|---|--------|--|
| 11 | INSPECT FOR SHORT TO GROUND BETWEEN LASER SENSOR AND CONNECTOR C-42 <ul style="list-style-type: none"> • Disconnect connector C-42. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between laser sensor terminal D and body ground — Between laser sensor terminal C and body ground • Is there continuity? | Yes | Go to the next step. |
| | | No | Go to Step 13. |
| 12 | INSPECT CAN LINE INSIDE LASER SENSOR FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the laser sensor connector. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between laser sensor terminal D (wiring harness side) and body ground — Between laser sensor terminal C (wiring harness side) and body ground • Is there continuity? | Yes | Repair or replace the wiring harness between the laser sensor and connector C-42 because the wiring harness is shorted to ground. |
| | | No | Replace the laser sensor because there is a short to ground in the laser sensor. (See LASER SENSOR REMOVAL/INSTALLATION.) |
| 13 | INSPECT FOR SHORT TO GROUND BETWEEN FORWARD SENSING CAMERA AND CONNECTOR C-42 <ul style="list-style-type: none"> • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between forward sensing camera terminal E and body ground — Between forward sensing camera terminal C and body ground • Is there continuity? | Yes | Go to the next step. |
| | | No | Go to Step 15. |
| 14 | INSPECT CAN LINE IN FORWARD SENSING CAMERA FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the forward sensing camera connector. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between forward sensing camera terminal E (wiring harness side) and body ground — Between forward sensing camera terminal C (wiring harness side) and body ground • Is there continuity? | Yes | Repair or replace the wiring harness between the forward sensing camera and connector C-42 because the wiring harness is shorted to ground. |
| | | No | Replace the forward sensing camera because there is a short to ground in the forward sensing camera. (See FORWARD SENSING CAMERA (FSC) REMOVAL/INSTALLATION.) |
| 15 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTORS C-11 AND C-42 <ul style="list-style-type: none"> • Connect connector C-42. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between forward sensing camera terminal E and body ground (with high beam control (HBC) system) — Between forward sensing camera terminal C and body ground (with high beam control (HBC) system) — Between laser sensor terminal D and body ground (with smart city brake support) — Between laser sensor terminal C and body ground (with smart city brake support) • Is there continuity? | Yes | Repair or replace the wiring harness between connector C-11 and connector C-42 because the wiring harness is shorted to ground. |
| | | No | Repair or replace the wiring harness between connector C-10 and connector C-11 because the wiring harness is shorted to ground. |
| 16 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-51, C-52 AND INSTRUMENT CLUSTER <ul style="list-style-type: none"> • Disconnect connector C-51, C-52. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between DLC-2 terminal F and body ground — Between DLC-2 terminal E and body ground • Is there continuity? | Yes | Go to Step 19. |
| | | No | Go to the next step. |

| Step | Inspection | Action | |
|------|--|--------|---|
| 17 | INSPECT FOR SHORT TO GROUND BETWEEN SAS CONTROL MODULE AND CONNECTOR C-51, C-52 <ul style="list-style-type: none"> Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between SAS control module terminal 3K and body ground Between SAS control module terminal 3L and body ground Is there continuity? | Yes | Go to the next step. |
| | | No | Repair or replace the wiring harness between connector C-11 and connector C-51, C-52 because the wiring harness is shorted to ground. |
| 18 | INSPECT CAN LINE IN SAS CONTROL MODULE FOR SHORT TO GROUND <ul style="list-style-type: none"> Disconnect the SAS control module connector. Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between SAS control module terminal 3K (wiring harness side) and body ground Between SAS control module terminal 3L (wiring harness side) and body ground Is there continuity? | Yes | Repair or replace the wiring harness between the SAS control module and connector C-51, C-52 because the wiring harness is shorted to ground. |
| | | No | Replace the SAS control module because there is a short to ground in the SAS control module. (See SAS CONTROL MODULE REMOVAL/ INSTALLATION.) |
| 19 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTORS C-34 AND DLC-2 <ul style="list-style-type: none"> Disconnect connector C-34. Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between DLC-2 terminal F and body ground Between DLC-2 terminal E and body ground Is there continuity? | Yes | Repair or replace the wiring harness between connector C-34 and DLC-2 because the wiring harness is shorted to ground. |
| | | No | Go to the next step. |
| 20 | INSPECT FOR SHORT TO GROUND BETWEEN START STOP UNIT AND CONNECTOR C-34 <ul style="list-style-type: none"> Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between start stop unit terminal 2M and body ground Between start stop unit terminal 2O and body ground Is there continuity? | Yes | Go to the next step. |
| | | No | Go to Step 22. |
| 21 | INSPECT CAN LINE IN START STOP UNIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Disconnect the start stop unit connector. Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between start stop unit terminal 2M (wiring harness side) and body ground Between start stop unit terminal 2O (wiring harness side) and body ground Is there continuity? | Yes | Repair or replace the wiring harness between the start stop unit and connector C-34 because the wiring harness is shorted to ground. |
| | | No | Replace the start stop unit because there is a short to ground in the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION.) |
| 22 | INSPECT FOR SHORT TO GROUND BETWEEN EPS CONTROL MODULE AND CONNECTOR C-34 <ul style="list-style-type: none"> Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between EPS control module terminal 2A and body ground Between EPS control module terminal 2D and body ground Is there continuity? | Yes | Go to the next step. |
| | | No | Go to Step 24. |
| 23 | INSPECT CAN LINE IN EPS CONTROL MODULE FOR SHORT TO GROUND <ul style="list-style-type: none"> Disconnect the EPS control module connector. Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between EPS control module terminal 2A (wiring harness side) and body ground Between EPS control module terminal 2D (wiring harness side) and body ground Is there continuity? | Yes | Repair or replace the wiring harness between the EPS control module and connector C-34 because the wiring harness is shorted to ground. |
| | | No | Replace the EPS control module because there is a short to ground in the EPS control module. (See STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION.) |

| Step | Inspection | Action |
|------|--|--------|
| 24 | INSPECT FOR SHORT TO GROUND BETWEEN INSTRUMENT CLUSTER AND CONNECTOR C-34 <ul style="list-style-type: none"> Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between instrument cluster terminal B and body ground Between instrument cluster terminal D and body ground Is there continuity? | Yes |
| | | No |
| 25 | INSPECT CAN LINE IN INSTRUMENT CLUSTER FOR SHORT TO GROUND <ul style="list-style-type: none"> Disconnect the instrument cluster connector. Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between instrument cluster terminal B (wiring harness side) and body ground Between instrument cluster terminal D (wiring harness side) and body ground Is there continuity? | Yes |
| | | No |
| 26 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-01 AND FRONT BODY CONTROL MODULE (FBCM) <ul style="list-style-type: none"> Disconnect connector C-01. Connect connector 2 which has front body control module (FBCM) terminals 2P and 2N. Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between DLC-2 terminal F and body ground Between DLC-2 terminal E and body ground Is there continuity? | Yes |
| | | No |
| 27 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-01 AND TCM <ul style="list-style-type: none"> Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between TCM terminal E and body ground Between TCM terminal F and body ground Is there continuity? | Yes |
| | | No |
| 28 | INSPECT CAN LINE IN TCM FOR SHORT TO GROUND <ul style="list-style-type: none"> Disconnect the TCM connector. Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between TCM terminal E (wiring harness side) and body ground Between TCM terminal F (wiring harness side) and body ground Is there continuity? | Yes |
| | | No |
| 29 | INSPECT FOR SHORT TO GROUND BETWEEN CONNECTORS C-32 AND C-01 <ul style="list-style-type: none"> Disconnect connector C-32. Connect connector C-01. Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between DLC-2 terminal F and body ground Between DLC-2 terminal E and body ground Is there continuity? | Yes |
| | | No |
| 30 | INSPECT FOR SHORT TO GROUND BETWEEN DSC HU/CM AND CONNECTOR C-32 <ul style="list-style-type: none"> Inspect for continuity at the following terminals: <ul style="list-style-type: none"> Between DSC HU/CM terminal AF and body ground Between DSC HU/CM terminal AC and body ground Is there continuity? | Yes |
| | | No |

| Step | Inspection | Action | |
|------|--|--------|--|
| 31 | INSPECT CAN LINE IN DSC HU/CM FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the DSC HU/CM connector. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between DSC HU/CM terminal AF (wiring harness side) and body ground — Between DSC HU/CM terminal AC (wiring harness side) and body ground • Is there continuity? | Yes | Repair or replace the wiring harness between the DSC HU/CM and connector C-32 because the wiring harness is shorted to ground. |
| | | No | Replace the DSC HU/CM because there is a short to ground in the DSC HU/CM. (See DSC HU/CM REMOVAL/INSTALLATION.) |
| 32 | INSPECT CAN LINE IN PCM FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between PCM terminal 2AK (wiring harness side) and body ground — Between PCM terminal 2AL (wiring harness side) and body ground • Is there continuity? | Yes | Repair or replace the wiring harness between the PCM and connector C-32 because the wiring harness is shorted to ground . |
| | | No | Replace the PCM because there is a short to ground in the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) |