


DTC P06DD:00 [SKYACTIV-D 2.2]

id0102s4215400

DTC P06DD:00	Engine oil pressure switch control circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> When the following condition is met, the engine oil pressure is exceeds 250 kPa {2.55 kgf/cm², 36.3 psi}: MONITORING CONDITIONS <ul style="list-style-type: none"> During low hydraulic pressure control (during engine oil solenoid valve operation) Engine speed is specified value or more. <ul style="list-style-type: none"> Idle speed or more when engine oil temperature is 40 °C {104 °F} or less (when cold) 1,800 rpm or more when engine oil temperature is 90 °C {194 °F} (when hot) 4,000 rpm or more when engine oil temperature is 135 °C {275 °F} or more (when hot) Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none"> Engine oil solenoid valve connector or terminals malfunction Engine oil temperature sensor/engine oil pressure sensor connector or terminals malfunction Short to ground or open circuit in engine oil solenoid valve power supply circuit <ul style="list-style-type: none"> Short to ground in wiring harness between ENGINE1 15 A fuse and engine oil solenoid valve terminal A ENGINE1 15 A fuse malfunction Open circuit in wiring harness between main relay terminal C and engine oil solenoid valve terminal A Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> Engine oil solenoid valve terminal B—PCM terminal 1CH Engine oil temperature sensor/engine oil pressure sensor terminal A—PCM terminal 1DN Engine oil temperature sensor/engine oil pressure sensor terminal D—PCM terminal 1DM PCM connector or terminals malfunction Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Engine oil solenoid valve terminal B—PCM terminal 1CH Engine oil temperature sensor/engine oil pressure sensor terminal A—PCM terminal 1DN Engine oil solenoid valve malfunction Engine oil pressure sensor malfunction Oil pump malfunction PCM malfunction

DTC P06DD: 00 Engine oil pressure switch control circuit high input



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
4	INSPECT ENGINE OIL SOLENOID VALVE CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the engine oil solenoid valve connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
5	INSPECT ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the engine oil temperature sensor/engine oil pressure sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
6	INSPECT ENGINE OIL SOLENOID VALVE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the engine oil solenoid valve and engine oil temperature sensor/engine oil pressure sensor connectors are disconnected. Switch the ignition ON (engine off). Measure the voltage at the engine oil solenoid valve terminal A (wiring harness-side). Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE1 15 A fuse. <ul style="list-style-type: none"> If the fuse is blown: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. Replace the fuse. If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the fuse. If the fuse is normal: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible open circuit. Go to Step 12.
7	INSPECT ENGINE OIL SOLENOID VALVE CIRCUIT AND ENGINE OIL PRESSURE SENSOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the engine oil solenoid valve and engine oil temperature sensor/engine oil pressure sensor connectors are disconnected. Switch the ignition off. Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> Engine oil solenoid valve terminal B Engine oil temperature sensor/engine oil pressure sensor terminal A Engine oil temperature sensor/engine oil pressure sensor terminal D Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 12.
		No	Go to the next step.
8	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
9	INSPECT ENGINE OIL SOLENOID VALVE CIRCUIT AND ENGINE OIL PRESSURE SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve and engine oil temperature sensor/engine oil pressure sensor and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Engine oil solenoid valve terminal B—PCM terminal 1CH — Engine oil temperature sensor/engine oil pressure sensor terminal A—PCM terminal 1DN • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 12.
10	INSPECT ENGINE OIL SOLENOID VALVE <ul style="list-style-type: none"> • Inspect the engine oil solenoid valve. (See ENGINE OIL SOLENOID VALVE INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the engine oil solenoid valve, then go to Step 12. (See ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
11	INSPECT ENGINE OIL PRESSURE SENSOR <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Inspect the engine oil pressure sensor. (See ENGINE OIL PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the engine oil temperature sensor/engine oil pressure sensor, then go to the next step. (See ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Replace the oil pump, then go to the next step. (See OIL PUMP REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
12	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Start the engine and warm it up completely. <p>Caution</p> <ul style="list-style-type: none"> • While performing this step, always operate the vehicle in a safe and lawful manner. • When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later. <ul style="list-style-type: none"> • Drive the vehicle under the FREEZE FRAME DATA (Mode 2)/snapshot data condition. • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
13	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.