

---




**DTC P1196:00 [SKYACTIV-D 2.2]**

id0102s4148800




<b>DTC P1196:00</b>	<b>Main relay control circuit problem</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"><li>• Main relay control voltage is <b>10 V or less</b> while the ignition switch is off.</li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>• This is a continuous monitor (other).</li><li>• The check engine light does not illuminate.</li><li>• FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.</li><li>• DTC is stored in the PCM memory.</li></ul>
<b>FAIL-SAFE FUNCTION</b>	Not applicable
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• Main relay malfunction</li><li>• Short to ground in wiring harness between main relay terminal E and PCM terminal 2K</li><li>• PCM connector or terminals malfunction</li><li>• Short to power supply in wiring harness between the following terminals:<ul style="list-style-type: none"><li>— Main relay terminal C—PCM terminal 2S</li><li>— Main relay terminal C—PCM terminal 2T</li><li>— Main relay terminal C—PCM terminal 1DH</li><li>— Main relay terminal C—PCM terminal 1DL</li></ul></li><li>• PCM malfunction</li></ul>

DTC  
P1196:00

## Main relay control circuit problem



PCM WIRING HARNESS-SIDE CONNECTOR



## Diagnostic Procedure

STEP	INSPECTION	ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes Go to the next step. No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> • Verify related Service Information availability. • Is any related Service Information available?	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step. No Go to the next step.

STEP	INSPECTION	ACTION	
3	<b>INSPECT MAIN RELAY</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Remove the main relay.</li> <li>• Inspect the main relay. (See RELAY INSPECTION.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the main relay, then go to Step 7.
		No	Go to the next step.
4	<b>INSPECT MAIN RELAY CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Main relay is removed.</li> <li>• Inspect for continuity between main relay terminal E (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness for a possible short to ground.</li> </ul> If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> Go to Step 7.
		No	Go to the next step.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
6	<b>INSPECT MAIN RELAY CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Main relay is removed.</li> <li>• Verify that the PCM connectors are disconnected.</li> <li>• Switch the ignition ON (engine off).</li> <li>• Measure the voltage at the main relay terminal C (wiring harness-side).</li> <li>• Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
7	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> Go to the next step.
		No	Go to the next step.
8	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.