

## MALFUNCTION DETECTION SOUND ACTIVATED [PARKING SENSOR]


id0903z4829400

### Note

- If there is any vehicle malfunction complaint lodged by a customer, perform FOREWORD [PARKING SENSOR] malfunction diagnosis according to the troubleshooting procedure.

### Description

- Buzzer sounds after turning the parking sensor switch/indicator on.



ac5wzw00002819

### Possible malfunction

- Front ultrasonic sensor, front corner ultrasonic sensor, rear ultrasonic sensor, and rear corner ultrasonic sensor malfunction
  - Dirt, damage (scratch, deformation), or freezing of sensor
  - Connector connection malfunction
  - Sensor malfunction
- Wiring harness malfunction
  - Front ultrasonic sensor and front corner ultrasonic sensor signal malfunction
    - Open circuit or short to ground in wiring harness between parking sensor control module terminal I and front corner ultrasonic sensor (LH) terminal B
    - Open circuit or short to ground in wiring harness between parking sensor control module terminal O and front corner ultrasonic sensor (RH) terminal B
    - Open circuit or short to ground in wiring harness between parking sensor control module terminal K and front ultrasonic sensor (LH) terminal B
    - Open circuit or short to ground in wiring harness between parking sensor control module terminal M and front ultrasonic sensor (RH) terminal B
  - Front ultrasonic sensor and front corner ultrasonic sensor ground system malfunction
    - L.H.D.**
      - Open circuit in wiring harness between parking sensor control module terminal J and terminal A for each sensor
    - R.H.D.**
      - Open circuit or short to ground in wiring harness between parking sensor control module terminal J and front corner ultrasonic sensor (LH) terminal A
      - Open circuit or short to ground in wiring harness between parking sensor control module terminal P and front corner ultrasonic sensor (RH) terminal A
      - Open circuit or short to ground in wiring harness between parking sensor control module terminal L and front ultrasonic sensor (LH) terminal A
      - Open circuit or short to ground in wiring harness between parking sensor control module terminal N and front ultrasonic sensor (RH) terminal A
- Rear ultrasonic sensor and rear corner ultrasonic sensor signal malfunction
  - Open circuit or short to ground in wiring harness between parking sensor control module terminal E and rear corner ultrasonic sensor (LH) terminal B
  - Open circuit or short to ground in wiring harness between parking sensor control module terminal G and rear corner ultrasonic sensor (RH) terminal B
  - Open circuit or short to ground in wiring harness between parking sensor control module terminal A and rear ultrasonic sensor (LH) terminal B
  - Open circuit or short to ground in wiring harness between parking sensor control module terminal C and rear ultrasonic sensor (RH) terminal B
- Rear ultrasonic sensor and rear corner ultrasonic sensor ground system malfunction
  - Open circuit in wiring harness between parking sensor control module terminal B and terminal A for each sensor
- Parking sensor control module malfunction

## Diagnostic Procedure

Step	Inspection		Action
1	<b>IDENTIFY MALFUNCTION LOCATION</b> <ul style="list-style-type: none"> <li>• Verify that the buzzer sounds from the parking sensor buzzer on either the front or rear.</li> <li>• Does the buzzer sound from the front parking sensor buzzer?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 7.
2	<b>VERIFY FRONT ULTRASONIC SENSOR CONDITION</b> <ul style="list-style-type: none"> <li>• Visually inspect the front ultrasonic sensor condition.</li> <li>• Is there any dirt, damage (scratch, deformation), and freezing on the sensor?</li> </ul>	Yes	Remove dirt, and then go to the next step.
		No	Go to the next step.
3	<b>INSPECT CONNECTOR CONNECTION CONDITION</b> <ul style="list-style-type: none"> <li>• Verify the connector connection conditions of the parking sensor control module, front ultrasonic sensor short-cord, and front ultrasonic sensor.</li> <li>• Are the connection conditions normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part.
4	<b>INSPECT WIRING HARNESS BETWEEN PARKING SENSOR CONTROL MODULE AND FRONT ULTRASONIC SENSOR FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Switch the ignition off (LOCK).</li> <li>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Disconnect the connectors of the front ultrasonic sensor and parking sensor control module.</li> <li>• Inspect for continuity between the following wiring harnesses: <b>L.H.D.</b> <ul style="list-style-type: none"> <li>— Parking sensor control module terminal I and front corner ultrasonic sensor (LH) terminal B</li> <li>— Parking sensor control module terminal O and front corner ultrasonic sensor (RH) terminal B</li> <li>— Parking sensor control module terminal K and front ultrasonic sensor (LH) terminal B</li> <li>— Parking sensor control module terminal M and front ultrasonic sensor (RH) terminal B</li> <li>— Parking sensor control module terminal J and terminal A for each sensor</li> </ul> <b>R.H.D.</b> <ul style="list-style-type: none"> <li>— Parking sensor control module terminal I and front corner ultrasonic sensor (LH) terminal B</li> <li>— Parking sensor control module terminal O and front corner ultrasonic sensor (RH) terminal B</li> <li>— Parking sensor control module terminal K and front ultrasonic sensor (LH) terminal B</li> <li>— Parking sensor control module terminal M and front ultrasonic sensor (RH) terminal B</li> <li>— Parking sensor control module terminal J and front corner ultrasonic sensor (LH) terminal A</li> <li>— Parking sensor control module terminal P and front corner ultrasonic sensor (RH) terminal A</li> <li>— Parking sensor control module terminal L and front ultrasonic sensor (LH) terminal A</li> <li>— Parking sensor control module terminal N and front ultrasonic sensor (RH) terminal A</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair for an open circuit in the wiring harness.

Step	Inspection	Action	
5	<b>INSPECT WIRING HARNESS BETWEEN PARKING SENSOR CONTROL MODULE AND FRONT ULTRASONIC SENSOR FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>Inspect for continuity between the following wiring harnesses: <ul style="list-style-type: none"> <li>— Parking sensor control module terminal I and ground</li> <li>— Parking sensor control module terminal O and ground</li> <li>— Parking sensor control module terminal K and ground</li> <li>— Parking sensor control module terminal M and ground</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness.
		No	Go to Step 10.
6	<b>VERIFY REAR ULTRASONIC SENSOR CONDITION</b> <ul style="list-style-type: none"> <li>Visually inspect the rear ultrasonic sensor condition.</li> <li>Is there any dirt, damage (scratch, deformation), and freezing on the sensor?</li> </ul>	Yes	Remove dirt, then go to the next step.
		No	Go to the next step.
7	<b>INSPECT CONNECTOR CONNECTION CONDITION</b> <ul style="list-style-type: none"> <li>Verify the connector connection conditions of the parking sensor control module, rear ultrasonic sensor short-cord, and rear ultrasonic sensor.</li> <li>Are the connection conditions normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part.
8	<b>INSPECT WIRING HARNESS BETWEEN PARKING SENSOR CONTROL MODULE AND REAR ULTRASONIC SENSOR FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Switch the ignition off (LOCK).</li> <li>Disconnect the connectors of the rear ultrasonic sensor and parking sensor control module.</li> <li>Inspect for continuity between the following wiring harnesses: <ul style="list-style-type: none"> <li>— Parking sensor control module terminal E and rear corner ultrasonic sensor (LH) terminal B</li> <li>— Parking sensor control module terminal G and rear corner ultrasonic sensor (RH) terminal B</li> <li>— Parking sensor control module terminal A and rear ultrasonic sensor (LH) terminal B</li> <li>— Parking sensor control module terminal C and rear ultrasonic sensor (RH) terminal B</li> <li>— Parking sensor control module terminal B and terminal A for each sensor</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair for an open circuit in the wiring harness.
9	<b>INSPECT WIRING HARNESS BETWEEN PARKING SENSOR CONTROL MODULE AND REAR ULTRASONIC SENSOR FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>Inspect for continuity between the following wiring harnesses: <ul style="list-style-type: none"> <li>— Parking sensor control module terminal E and ground</li> <li>— Parking sensor control module terminal G and ground</li> <li>— Parking sensor control module terminal A and ground</li> <li>— Parking sensor control module terminal C and ground</li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness.
		No	Go to the next step.
10	<b>DETERMINE IF MALFUNCTION CAUSE IS ULTRASONIC SENSOR OR PARKING SENSOR CONTROL MODULE</b> <ul style="list-style-type: none"> <li>Reconnect all the disconnected connectors.</li> <li>Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>Switch the ignition ON (engine off or on).</li> <li>Turn the parking sensor switch/indicator on.</li> <li>Refer to the parking sensor control module inspection and verify the generated pulse for each sensor. (See PARKING SENSOR CONTROL MODULE INSPECTION.)</li> <li>Can the generated pulse be verified?</li> </ul>	Yes	Replace the parking sensor control module. (See PARKING SENSOR CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Replace the ultrasonic sensor. (See FRONT ULTRASONIC SENSOR REMOVAL/INSTALLATION.) (See REAR ULTRASONIC SENSOR REMOVAL/INSTALLATION.)