

DTC C0061:29/C0062:29/C0063:29/P0666:29

id080200890200

System malfunction location	<ul style="list-style-type: none">• C0061:29: Low-G sensor (lateral-G) in SAS control module (internal circuit disabled)• C0062:29: Low-G sensor (forward-G) in SAS control module (internal circuit disabled)• C0063:29: Yaw rate sensor in SAS control module (internal circuit disabled)• P0666:29: Temperature sensor in SAS control module (internal circuit disabled)
Detection condition	Warning <ul style="list-style-type: none">• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure. <ul style="list-style-type: none">• SAS control module internal sensor has a malfunction
Fail-safe	—
Possible cause	<ul style="list-style-type: none">• SAS control module malfunction
System wiring diagram	—

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	PERFORM SAS CONTROL MODULE DTC INSPECTION <ul style="list-style-type: none">• Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC.)• Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION.)• Are the same DTCs present?	Yes	Replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION.)
		No	DTC troubleshooting completed.