
TROUBLESHOOTING INDEX

id080300802000

- Use the chart below verify the symptoms of the trouble in order to diagnose the appropriate area.

No.	Troubleshooting item	Description	Page
1	Air bag system warning light does not illuminate.	Air bag system warning light does not illuminate while the air bag system is performing initialization.	(See NO.1 AIR BAG SYSTEM WARNING LIGHT DOES NOT ILLUMINATE)
2	Air bag system warning light illuminates constantly.	Air bag system warning light is illuminated constantly and remains illuminated after 6 s have elapsed.	(See NO.2 AIR BAG SYSTEM WARNING LIGHT ILLUMINATES CONSTANTLY)