


DTC B10AC:13 [START STOP UNIT]

id0902p6019700



Diagnostic Procedure

Step	Inspection	Action
1	PERFORM INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA) <ul style="list-style-type: none"> Using the M-MDS, perform the instrument cluster configuration with the As-Built data. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).) Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) Switch the ignition ON (engine off or on) and wait for 5 s or more. Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) Is DTC B10AC:13 displayed? 	<div>Yes</div> Using the M-MDS, re-perform the instrument cluster configuration using the As-Built data, then go to the next step. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).) <div>No</div> Go to Step 8.

Step	Inspection	Action	
2	INSPECT CLOCK SPRING CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Disconnect the clock spring connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
3	INSPECT CLOCK SPRING <ul style="list-style-type: none"> • Inspect the clock spring. (See CLOCK SPRING INSPECTION.) • Is the clock spring normal? 	Yes	Go to the next step.
		No	Replace the clock spring, then go to Step 7. (See CLOCK SPRING REMOVAL/INSTALLATION.)
4	INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the start stop unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
5	INSPECT CRUISE CONTROL SWITCH CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the start stop unit and clock spring connectors are disconnected. • Inspect the wiring harness between the following terminals (vehicle wiring harness side) for continuity. <ul style="list-style-type: none"> — Start stop unit terminal 1Y and clock spring (start stop unit side) terminal J — Start stop unit terminal 1Z and clock spring (start stop unit side) terminal N • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness which has an open circuit, then go to Step 7.
6	INSPECT CRUISE CONTROL SWITCH <ul style="list-style-type: none"> • Inspect the cruise control switch. (See CRUISE CONTROL SWITCH INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See CRUISE CONTROL SWITCH INSPECTION [SKYACTIV-D 2.2].) • Is the cruise control switch normal? 	Yes	Go to the next step.
		No	Replace the cruise control switch, then go to the next step. (See STEERING SWITCH REMOVAL/INSTALLATION.)

Step	Inspection	Action
7	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Switch the ignition ON (engine off or on) and wait for 5 s or more. • Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is DTC B10AC:13 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
8	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No DTC troubleshooting completed.