

The diagram illustrates the assembly of the engine and its components. The main exploded view shows the following parts:

- 10: Flywheel
- 9: Crankshaft
- 8: Piston and connecting rod assembly
- 7: Piston pin
- 6: Piston pin clip

The diagram also includes two side views of the engine assembly:

- R.H.D. (Right Hand Drive):** Shows the engine with the flywheel (10) and crankshaft (9) installed. The piston and connecting rod (8) are shown being inserted into the crankshaft. The piston pin (7) and piston pin clip (6) are shown being inserted into the piston. The flywheel is shown being bolted to the crankshaft.
- L.H.D. (Left Hand Drive):** Shows the engine with the flywheel (10) and crankshaft (9) installed. The piston and connecting rod (8) are shown being inserted into the crankshaft. The piston pin (7) and piston pin clip (6) are shown being inserted into the piston. The flywheel is shown being bolted to the crankshaft.

1	Reserve tank (See CLUTCH FLUID INSPECTION [D66M-R, D66MX-R].) (See CLUTCH FLUID REPLACEMENT/AIR BLEEDING [D66M-R, D66MX-R].)
2	Clutch master cylinder (See CLUTCH MASTER CYLINDER REMOVAL/ INSTALLATION [D66M-R, D66MX-R].)

3	Clutch pedal (See CLUTCH PEDAL INSPECTION [D66M-R, D66MX-R].) (See CLUTCH PEDAL REMOVAL/INSTALLATION [D66M-R, D66MX-R].) (See CLUTCH PEDAL POSITION SWITCH REMOVAL/INSTALLATION [D66M-R, D66MX-R].) (See STARTER INTERLOCK SWITCH REMOVAL/INSTALLATION [D66M-R, D66MX-R].)
4	Clutch pipe and hose (See CLUTCH FLUID LEAKAGE INSPECTION [D66M-R, D66MX-R].) (See CLUTCH PIPE AND HOSE REMOVAL/INSTALLATION [D66M-R, D66MX-R].)
5	Clutch release cylinder (See CLUTCH RELEASE CYLINDER REMOVAL/INSTALLATION [D66M-R, D66MX-R].)
6	Clutch unit (See CLUTCH UNIT REMOVAL/INSTALLATION [D66M-R, D66MX-R].)
7	Clutch release collar (See CLUTCH RELEASE COLLAR INSPECTION [D66M-R, D66MX-R].) (See CLUTCH UNIT REMOVAL/INSTALLATION [D66M-R, D66MX-R].)

8	Clutch cover (See CLUTCH COVER INSPECTION [D66M-R, D66MX-R].) (See CLUTCH UNIT REMOVAL/INSTALLATION [D66M-R, D66MX-R].)
9	Clutch disc (See CLUTCH DISC INSPECTION [D66M-R, D66MX-R].) (See CLUTCH UNIT REMOVAL/INSTALLATION [D66M-R, D66MX-R].)
10	Dual-mass flywheel (See DUAL-MASS FLYWHEEL INSPECTION [D66M-R, D66MX-R].) (See CLUTCH UNIT REMOVAL/INSTALLATION [D66M-R, D66MX-R].)