
HEADLIGHT LEVELING SWITCH REMOVAL/INSTALLATION

id091800803600

Note

- The headlight leveling switch is integrated with the cluster switch.
- For the cluster switch removal/installation, refer to “SWITCH PANEL REMOVAL/INSTALLATION” because the cluster switch is installed to the switch panel. (See SWITCH PANEL REMOVAL/INSTALLATION.)