

**DTC U0415:68 [LASER SENSOR]**

id0402c4895100

DTC	U0415:68	Abnormal message from DSC HU/CM
<b>DETECTION CONDITION</b>	• Correct data cannot be received from DSC HU/CM	
<b>FAIL-SAFE FUNCTION</b>	• Inhibits the smart city brake support (SCBS) controls. • Illuminates the master warning light • The message "SCBS Inspection Required" is indicated in the display.	
<b>POSSIBLE CAUSE</b>	• DSC HU/CM malfunction	
<b>SYSTEM WIRING DIAGRAM</b>	—	

**Diagnostic procedure**

STEP	INSPECTION		ACTION
1	<b>INSPECT FOR DSC HU/CM MALFUNCTION</b> <ul style="list-style-type: none"><li>• Switch the ignition to off.</li><li>• Using the M-MDS, perform the DTC inspection for the DSC HU/CM. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)</li><li>• Are any DTCs detected?</li></ul>	Yes	Go to applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)
		No	Go to the next step.
2	<b>VERIFY THAT THE SAME DTC IS NOT PRESENT</b> <ul style="list-style-type: none"><li>• Clear the DTCs from the memory. (See ON-BOARD DIAGNOSIS [LASER SENSOR].)</li><li>• Are the same DTCs present?</li></ul>	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	<b>VERIFY THAT NO OTHER DTCS ARE PRESENT</b> <ul style="list-style-type: none"><li>• Are any other DTCs output?</li></ul>	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [LASER SENSOR].)
		No	DTC troubleshooting completed.