

---

**NO.7 TCS/DSC INDICATOR LIGHT FLASHES (WHEN NEITHER THE TCS NOR THE DSC ARE OPERATING)  
[DYNAMIC STABILITY CONTROL (DSC)]**

id0403b2896200

<b>7</b>	<b>TCS/DSC indicator light flashes (when neither the TCS nor the DSC are operating)</b>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• Non-completion of DSC related parts sensor initialization. (If the initialization is not carried out after replacing the DSC HU/CM and/or SAS control module, a TCS/DSC indicator light will flash. In this case, the DSC is not detected.)</li></ul>

**Diagnostic procedure**

<b>STEP</b>	<b>INSPECTION</b>		<b>ACTION</b>
1	<b>INSPECT CONNECTION OF DSC HU/CM AND SAS CONTROL MODULE CONNECTORS</b> <ul style="list-style-type: none"><li>• Inspect for connection of DSC HU/CM and SAS control module (yaw rate sensor, low-G sensor) connectors.</li><li>• Are DSC HU/CM and SAS control module connectors connected securely?</li></ul>	Yes	Perform the initialization procedure. (See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.)
		No	Perform the initialization procedure after connect the suspected connector securely. (See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.)