

## VEHICLE MOVES IN P POSITION, OR PARKING GEAR DOES NOT DISENGAGE WHEN P IS DISENGAGED [GW6A-EL, GW6AX-EL]

id050320100600

<b>TROUBLESHOOTING ITEM</b>	<b>Vehicle moves in P position, or parking gear does not disengage when P is disengaged</b>
<b>DESCRIPTION</b>	<ul style="list-style-type: none"> <li>• Vehicle rolls when on a downward slope in P position.</li> <li>• Vehicle does not move in D, M and R position when accelerator pedal is depressed, and engine remains in stalled condition.</li> </ul>
<b>POSSIBLE CAUSE</b>	1. Parking mechanism malfunction

### Diagnostic procedure

<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>
1	<b>INSPECT PARKING MECHANISM FOR MALFUNCTION</b> <ul style="list-style-type: none"> <li>• When the vehicle is stopped on a flat, level road and the engine is off, does the vehicle move when pushed? (In D, N or R position with the brake pedal released.)</li> </ul>	Yes Symptom troubleshooting is completed.
		No Replace the parking mechanism. (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [GW6A-EL].) (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [GW6AX-EL].)