

DTC P0327:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4703000

DTC P0327:00	KS circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors input signal from the KS. If the input voltage is below specified value for 5 s, the PCM determines that the KS circuit has a malfunction. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Sets the knocking spark retard correction value of the ignition control to the fixed value.
POSSIBLE CAUSE	<ul style="list-style-type: none"> KS connector or terminals malfunction KS malfunction Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> KS terminal A—PCM terminal 1H KS terminal B—PCM terminal 1D PCM connector or terminals malfunction KS circuits are shorted to each other Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> KS terminal A—PCM terminal 1H KS terminal B—PCM terminal 1D PCM malfunction

④

KS

KS WIRING HARNESS-SIDE CONNECTOR

PCM WIRING HARNESS-SIDE CONNECTOR

PCM

④

KS

KS WIRING HARNESS-SIDE CONNECTOR

PCM WIRING HARNESS-SIDE CONNECTOR

PCM

④

KS

KS WIRING HARNESS-SIDE CONNECTOR

PCM WIRING HARNESS-SIDE CONNECTOR

PCM

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes No	Go to the next step. Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	INSPECT KS CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the KS connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	INSPECT KS <ul style="list-style-type: none"> • Inspect the KS. (See KNOCK SENSOR (KS) INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is there any malfunction? 	Yes	Replace the KS, then go to Step 9.
		No	(See KNOCK SENSOR (KS) REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
5	INSPECT KS CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the KS connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — KS terminal A — KS terminal B • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to Step 9.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
7	INSPECT KS CIRCUITS FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the KS and PCM connectors are disconnected. • Inspect for continuity between KS terminals A and B (wiring harness-side). • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 9.
		No	Go to the next step.
8	INSPECT KS CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the KS and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — KS terminal A—PCM terminal 1H — KS terminal B—PCM terminal 1D • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Start the engine. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
10	VERIFY AFTER REPAIR PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.