

DTC U0423:68 [REAR VEHICLE MONITORING SYSTEM]

id0902z2888900

System malfunction location	Error signal received from instrument cluster
Detection condition	• The rear vehicle monitoring control module (RH) receives malfunction signal from the instrument cluster for 2 s or more .
Fail-safe	• Inhibits the rear vehicle monitoring system.
Possible cause	• DTCs are stored in the instrument cluster. • Instrument cluster malfunction • Rear vehicle monitoring control module (RH) malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	VERIFY INSTRUMENT CLUSTER DTCs • Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Is the DTC displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No Go to the next step.
2	INSPECT INSTRUMENT CLUSTER • Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) • Is the instrument cluster normal?	Yes Go to the next step.
		No Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
3	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS INSTRUMENT CLUSTER • Clear the DTC for the rear vehicle monitoring control module using the M-MDS. (See CLEARING DTC [REAR VEHICLE MONITORING SYSTEM].) • Switch the ignition ON (engine off or on) and wait for 2 s or more . • Perform the DTC inspection for the rear vehicle monitoring control module using the M-MDS. (See DTC INSPECTION [REAR VEHICLE MONITORING SYSTEM].) • Is DTC U0423:68 displayed?	Yes Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No Go to Step 5.
4	VERIFY THAT REPAIRS HAVE BEEN COMPLETED • Clear the DTC for the rear vehicle monitoring control module using the M-MDS. (See CLEARING DTC [REAR VEHICLE MONITORING SYSTEM].) • Switch the ignition ON (engine off or on) and wait for 2 s or more . • Perform the DTC inspection for the rear vehicle monitoring control module using the M-MDS. (See DTC INSPECTION [REAR VEHICLE MONITORING SYSTEM].) • Is DTC U0423:68 displayed?	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the rear vehicle monitoring control module (RH), then go to the next step. (See REAR VEHICLE MONITORING CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to the next step.
5	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR VEHICLE MONITORING SYSTEM].)
		No DTC troubleshooting completed.