
M POSITION INDICATOR LIGHT DOES NOT ILLUMINATE IN M POSITION/M POSITION INDICATOR LIGHT ILLUMINATES IN D POSITION [FW6A-EL, FW6AX-EL]

id050317103200

TROUBLESHOOTING ITEM	M position indicator light does not illuminate in M position/M position indicator light illuminates in D position
DESCRIPTION	• M position indicator light in instrument cluster does not illuminate in M position or M position indicator light in instrument cluster in P, R, N and D positions with the ignition switched ON (engine off or on).
POSSIBLE CAUSE	1. Instrument cluster malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	INSPECT INSTRUMENT CLUSTER FOR MALFUNCTION • Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) • Is there any malfunction?	Yes Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)
		No Symptom troubleshooting is completed.