
SYMPTOM TROUBLESHOOTING [INSTRUMENT CLUSTER]

id0903d5715100

Troubleshooting item
FUEL GAUGE READING IS NOT CORRECT [INSTRUMENT CLUSTER]
LOW ENGINE COOLANT TEMPERATURE INDICATOR LIGHT/HIGH ENGINE COOLANT TEMPERATURE WARNING LIGHT ILLUMINATES OR FLASHES CONTINUOUSLY [INSTRUMENT CLUSTER]