

TROUBLESHOOTING INDEX [CD PLAYER]

id0903k3801000

Troubleshooting Index

Items	Symptom	Possible DTC	
		Using the M-MDS	Without using M-MDS (On-board diagnostic test mode)
CD player	CD PLAYER DOES NOT LOAD THE CD OR EJECTS THE CD IMMEDIATELY [CD PLAYER]	B1D19:79	10:Er01
	CD PLAYER DOES NOT EJECT THE CD [CD PLAYER]	B1D19:79	10:Er01
	CD PLAYER DOES NOT PLAY THE CD/NO SOUND [CD PLAYER]	B1188:64	10:Er07
	SOUND JUMPS [CD PLAYER]	B1188:64	10:Er07
	CD PLAYER SCRATCHES ON THE CD [CD PLAYER]	B1188:64	10:Er07
CD player (MP3/WMA formatted file playback function)	CD PLAYER DOES NOT PLAY THE MP3/ WMA-FORMATTED FILE [CD PLAYER]	B1188:64	10:Er07
	MP3/WMA-FORMATTED FILE FOLDER SELECTION IS INOPERATIVE/TRACK SEARCH IS INOPERATIVE [CD PLAYER]	B1D19:71	10:Er02
	CD PLAYER DOES NOT INDICATE THE MP3/WMA TITLE TEXT [CD PLAYER]	B1D19:71, B1188:64	10:Er02, 10:Er07
	CD PLAYER DOES NOT PLAY THE AUDIO DATA (CDDA) [CD PLAYER]	B1D19:71, B1188:64	10:Er02, 10:Er07
CD player	TRACK CHANGE IS INOPERATIVE [CD PLAYER]	B1D19:71	10:Er02

Quick Diagnostic Chart

		X: Applicable									
Possible factor	Troubleshooting Item	CD player					MP3/WMA (Windows media audio) applicable CD player				CD player
		CD player does not load the CD or ejects the CD immediately	CD player does not eject the CD	CD player does not play the CD/No sound	Sound jumps	CD player scratches on the CD	CD player does not play the MP3/WMA-formatted file	MP3/WMA-formatted file folder selection is inoperative /track search is inoperative	CD player does not indicate the MP3/WMA title text	CD player does not play the audio data (CODA)	Track change is inoperative
Insertion angle of disc incorrect		X									
CD is inserted upside down		X									
Defective CD (egg., cracked, badly bent, rough edges, scratch, dirty CD, condensation)		X	X	X	X						X
Non-conventional discs (e.g., 8 cm (3 in) disc adapter, heart-shaped disc, octagonal disc)		X	X	X							X
Deformed disc is used (e.g., out of specification (thickness), bent disc)		X	X			X					
Poor connection of audio unit connector or terminal (e.g., damaged, bent, pull-out pin, corrosion)		X	X								
Audio unit malfunction		X	X	X	X	X	X	X	X	X	X
Multiple CDs are inserted into the CD player at the same time			X			X					
CD is inserted upside down				X							
Improper audio unit installation (e.g., rattle, loose)					X						
Inadequate tire pressure					X						
Improper panel switch installation											
Audio panel switch malfunction											X
CD-R/RW written format is out of specification							X			X	
MP3/WMA and other format data are in the CD-R/RW							X				
File extension for MP3/WMA-formatted file is incorrect (Correct: ".mp3"/".wma", Incorrect: e.g., RIFF)							X				
Defective CD-R/RW (e.g., dirty, scratch)							X	X	X	X	
Conflict of ID tag version for CD-R/RW								X	X		
Improper folder and/or music title in CD-R/RW								X			
The number of characters of folder/music file name in CD-R/RW exceeds the maximum number of characters								X	X		
Improper encode in CD-R/RW								X	X		
No title input in CD-R/RW									X		
Input title text by 2-bytes characters									X		
Data other than the audio data is in CD-R/RW										X	