

---

## CLEARING DTC [IMMOBILIZER SYSTEM]

id0902e4028600

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
  - (1) Select "Self Test".
  - (2) Select "All CMDTCs".
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition to off.
6. Switch the ignition ON (engine off or on) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION [IMMOBILIZER SYSTEM].)
8. Verify that no DTCs are displayed.