


**DTC U0298:00 [SKYACTIV-D 2.2]**

id0102s4910500

**Details On DTCs**

<b>DTC U0298:00</b>	<b>CAN/LIN communication system: DC-DC converter information communication error with front body control module (FBCM)</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"><li>• PCM detects a DC-DC converter information communication error from front body control module (FBCM).</li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>• This is a continuous monitor (other).</li><li>• The check engine light does not illuminate.</li><li>• FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.</li><li>• DTC is stored in the PCM memory.</li></ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"><li>• Inhibits engine-stop by operating the i-stop function.</li></ul>
<b>VEHICLE STATUS WHEN DTCs ARE OUTPUT</b>	<ul style="list-style-type: none"><li>• Flashes i-stop warning light (amber).</li></ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• Communication line between DC-DC converter and front body control module (FBCM) malfunction</li><li>• DC-DC converter connector or terminals malfunction</li><li>• Short to ground or open circuit in DC-DC converter power supply circuit<ul style="list-style-type: none"><li>— Short to ground in wiring harness between GLOW 80 A fuse and DC-DC converter terminal L</li><li>— GLOW 80 A fuse malfunction</li><li>— DCDC DE 40 A fuse malfunction</li><li>— Open circuit in wiring harness between battery positive terminal and DC-DC converter terminal L</li></ul></li><li>• Short to ground or open circuit in DC-DC converter power supply circuit<ul style="list-style-type: none"><li>— Short to ground in wiring harness between C/U IG1 15 A fuse and DC-DC converter terminal H</li><li>— C/U IG1 15 A fuse malfunction</li><li>— Open circuit in wiring harness between IG1 relay terminal C and DC-DC converter terminal H</li></ul></li><li>• Front body control module (FBCM) connector or terminals malfunction</li><li>• Short to ground in wiring harness between the following terminals:<ul style="list-style-type: none"><li>— DC-DC converter terminal C—Front body control module (FBCM) terminal 2H</li><li>— Front body control module (FBCM) terminal 2P—PCM terminal 2AK</li><li>— Front body control module (FBCM) terminal 2N—PCM terminal 2AL</li></ul></li><li>• Open circuit in wiring harness between DC-DC converter terminal C and front body control module (FBCM) terminal 2H</li><li>• DC-DC converter malfunction</li><li>• Front body control module (FBCM) malfunction</li></ul>



### Repeatability Verification Procedure

1. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)
2. Start the engine.

### Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
3	<b>INSPECT DC-DC CONVERTER CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the DC-DC converter connector.</li> <li>• Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
4	<b>INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter connector is disconnected.</li> <li>• Measure the voltage at the DC-DC converter terminal L (wiring harness-side).</li> <li>• Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the GLOW 80 A fuse and DCDC DE 40 A fuse. <ul style="list-style-type: none"> <li>• If the fuse is burnt out:               <ul style="list-style-type: none"> <li>— Refer to the wiring diagram and verify whether or not there is a common connector between GLOW 80 A fuse and DC-DC converter terminal L.</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> <li>• Replace the fuse.</li> </ul> </li> <li>• If the fuse is damaged:               <ul style="list-style-type: none"> <li>— Replace the fuse.</li> </ul> </li> <li>• If all fuses are normal:               <ul style="list-style-type: none"> <li>— Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and DC-DC converter terminal L.</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> </li> </ul> Go to Step 12.

STEP	INSPECTION	ACTION	
5	<b>INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter connector is disconnected.</li> <li>• Switch the ignition ON (engine off).</li> <li>• Measure the voltage at the DC-DC converter terminal H (wiring harness-side).</li> <li>• Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the C/U IG1 15 A fuse. <ul style="list-style-type: none"> <li>• If the fuse is burnt out:               <ul style="list-style-type: none"> <li>— Refer to the wiring diagram and verify whether or not there is a common connector between C/U IG1 15 A fuse and DC-DC converter terminal H.</li> </ul> </li> <li>• <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> </li> <li>• <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> <li>• Replace the fuse.</li> </ul> </li> <li>• If the fuse is damaged:               <ul style="list-style-type: none"> <li>— Replace the fuse.</li> </ul> </li> <li>• If the fuse is normal:               <ul style="list-style-type: none"> <li>— Refer to the wiring diagram and verify whether or not there is a common connector between IG1 relay terminal C and DC-DC converter terminal H.</li> </ul> </li> <li>• <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> </li> <li>• <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> </li> </ul> Go to Step 12.
6	<b>INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the front body control module (FBCM) connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
7	<b>INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected.</li> <li>• Inspect for continuity between DC-DC converter terminal C (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between DC-DC converter terminal C and front body control module (FBCM) terminal 2H. <ul style="list-style-type: none"> <li>• <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> </li> <li>• <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> </li> </ul> Go to Step 12.
		No	Go to the next step.

STEP	INSPECTION		ACTION
8	<b>INSPECT FRONT BODY CONTROL MODULE (FBCM) CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>— Front body control module (FBCM) terminal 2P</li> <li>— Front body control module (FBCM) terminal 2N</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	<p>If the short to ground circuit could be detected in the wiring harness:</p> <ul style="list-style-type: none"> <li>• Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>— Front body control module (FBCM) terminal 2P—PCM terminal 2AK</li> <li>— Front body control module (FBCM) terminal 2N—PCM terminal 2AL</li> </ul> </li> </ul> <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>— Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>— Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness which has a short to ground.</li> </ul> <p>If the short to ground circuit could not be detected in the wiring harness:</p> <ul style="list-style-type: none"> <li>• Replace the front body control module (FBCM) or DC-DC converter. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.) (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> <p>Go to Step 12.</p>
		No	Go to the next step.
9	<b>INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected.</li> <li>• Inspect for continuity between DC-DC converter terminal C (wiring harness-side) and front body control module (FBCM) terminal 2H (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	<p>Refer to the wiring diagram and verify whether or not there is a common connector between DC-DC converter terminal C and front body control module (FBCM) terminal 2H.</p> <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> <p>Go to Step 12.</p>
10	<b>INSPECT DC-DC CONVERTER</b> <ul style="list-style-type: none"> <li>• Inspect the DC-DC converter. (See DC-DC CONVERTER INSPECTION [SKYACTIV-D 2.2].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the DC-DC converter, then go to Step 12. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
11	<b>INSPECT FRONT BODY CONTROL MODULE (FBCM)</b> <ul style="list-style-type: none"> <li>• Inspect the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) INSPECTION.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
12	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Implement the repeatability verification procedure. (See Repeatability Verification Procedure.)</li> <li>• Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1.
		No	Go to the next step.
13	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.